



- 1) Login to the Web Interface of the machine
- 2) Select Device Management/Configuration



- 3) Under Device Settings Select "Email"



- 4) Enter Administrator Email Address as senders email address as well as SMTP Auth. Email Address and User Name.
- 5) Enter SMTP Server Name and port no.
- 6) Select appropriate SSL Setting

Email

OK

Cancel

■ Administrator Email Address

:

scan@test.com

Create Email Signature

■ Signature

:

Reception

■ Reception Protocol

:

POP3

▼

■ Email Reception Interval

:

☒ On ☐ Off

:

15

minute(s)

■ Max. Reception Email Size

:

2

MB

■ Email Storage in Server

:

Off

▼

SMTP

■ SMTP Server Name

:

mail.smtp.com

■ SMTP Port No.

:

25

■ Use Secure Connection (SSL)

:

☒ On ☐ Off

■ SMTP Authentication

:

☒ On ☐ Off

■ SMTP Auth. Email Address

:

scan@test.com

■ SMTP Auth. User Name

:

scan@test.com

■ SMTP Auth. Password

:

Change

■ SMTP Auth. Encryption

:

Auto Select

▼

POP before SMTP

- 7) Select Change to enter password
- 8) Enter password and select ok
- 9) Select OK again to save changes.