


USER MANUAL

Signature Pendant 30/70



IMPORTANT NOTICE:

Before installation make sure power is OFF!

Always use professional electrician for installations.


1. Cable is attached to ceiling hook with plastic loop. Length can be adjusted by loosening the screw underneath the ceiling cup and sliding the cable through the loop. Cable length is 2 meters.

2. Electrical wire is connected to mains power. Important notice: Make sure power is turned off! Always use a professional for electricity installations!

3. Ceiling cup is pushed up against ceiling. Secure cup to it's place by tightening the screw underneath.

4. Lamp holder is attached to lamp shade. Please tighten lamp holder ring securely.

5. Attach light bulb to lamp holder.



Important notice:


Use size E27 max 57W light bulbs only!

We recommend using LED lights.

For example:


Osram led superstar classic E27 6W

Philips led bulb E27 6W



INSTRUKTIONER

Signature Pendant 30/70



VIKTIGT:

Före installation, se till att strömmen är AV!
Anlita alltid en professionell elektriker för installationer.


1. Häng lampan i takkroken med plastöglan. Justera längden på sladden genom att låta på skruven under takkoppen och dra sladden genom öglan. Sladden är 2 meter.

2. Anslut sladden till elnätet. Obs! Se till att strömmen är avstängd! Använd alltid en fackman för elinstallationer!

3. Takkoppen skjuts upp mot taket och fäst på sin plats genom att skruva åt fästet under takkoppen.

4. Fäst lamphållaren på lampskärmen. Dra åt ringen ordentligt.

5. Skruva i glödlampan i lamphållaren.



Viktigt:

Använd enbart E27 max 57W glödlampor!
Vi rekommenderar LED belysning

Till exempel:

Osram led superstar classic E27 6W
Philips led bulb E27 6W

