


OWWL

SEMI-EMPOTRADO
SEMI-RECESSED

Ref. 26122-



Nexia
Culture x light

NEXIA ILUMINACIÓN S.L.
Polígono Industrial Can Carner
C/ Priorat, 14-20, 08211 Castellar del Vallès
Barcelona, SPAIN
Tel. +34 93 715 47 12
info@nexia.es www.nexia.es

FIG-1

D = Ø100mm d= MAX: 20mm






FIG-2

2A- Retirar la tapa y realizar las conexiones.
CII / DALI / CII / ON-OFF
2A-Remove the cover and make the
connections. CII / DALI / CII / ON-OFF

2A DALI
DALI

2B- Montar la tapa y fijar
con tornillo.
2B-Mount the cover and fix
with a screw.


2B



2A ON-OFF
ON-OFF

FIG-3

3A- Introducir el DRIVER en el techo.
3A-Insert the DRIVER into the ceiling.



3B- Abrir los muelles e introducir la base.
3B- Open the springs and insert the base.

FIG-4

Verificar que el giro y basculación es correcta.
Verify that the rotation and tilting is correct.




FIG-5

Ajustar el ángulo girando el aro frontal.
Adjust the beam angle via rotating the front ring.

