
IT12	Basic size	0-30	30-100	100-300	300-600	600-1000	>1000
	Tolerance	±0.15	±0.25	±0.35	±0.5	±0.8	±1.0
	Unit	mm	mm	mm	mm	mm	mm

Note: unless stated otherwise, untoleranced dimensions follow this table.

Ver.	Zone	Change	By	Date





straight cabinet top view