

Multi Box Modification For Retrofit

Installation Guide



DUCTMATE®
Industries, Inc.

1-800-245-3188

www.ductmate.com

ductmate@ductmate.com

Multi Box Modification For Retrofit

Installation Guide


The parts included in the multi box adapter will allow you to double the amount of corners you load at once onto your retrofitted Cornermatic dual head or single head machine.

There are 2 parts included in this modification kit:

1. The part shown here is the box retainer for the bottom chute.
2. The part shown here is the coupler to connect 2 sleeves.



Begin with the box retainer for the bottom chute. If the bottom chute is already installed it must be removed to insert this part. (Note that on a dual head machine, the upper chute does not require this box retainer).




This is what it looks like when installed properly.




Proceed loading the first sleeve of corners onto the retrofitted machine.



Next tear the top off of this box of corners.



Put the dual stack coupler on the sleeve.



Note that the tab on the inside of the coupler must go over top of the cardboard of the sleeve.



Lower the spine of the coupler.



Tear the perforated tab off of the bottom of an additional sleeve of corners and place on the coupler on top of the existing one.



Lift the spine, to ensure that the top sleeve doesn't tip.



Now 160 corners are ready for use.



Charleroi, PA	Lodi, CA
210 Fifth Street	810 S. Cluff Avenue
Charleroi, PA 15022	Lodi, CA 95240-9141
800-245-3188	800-245-3188
724-258-0500	724-258-0500
FAX: 724-258-5494	FAX: 209-333-4678

www.ductmate.com