Golden Rays 真无线蓝牙耳机

Instructions

Package list

(The pictures are for reference only, please refer to the actual product.)

Product Description

Notice:
Do not use in an environment with high temperature and humid.
Frequently the volume too high for a long time may cause hearing loss.
Please read the instructions before the first time the Bluetooth Enabled Wireless Headphones.

Connection

Connecting with new device
1.Put the earpieces into the charging case and keep the lids open.
2.Long press the function button on the charging case for 3 seconds until the indicator flashes red and blue alternately, then the headphones enter the pairing mode.
3.Turn on the Bluetooth function of your device and search for the Bluetooth headphones, then click the Bluetooth headphones to complete the pairing.
*Reminding: Golden Rays, on the first pairing.

Connecting to the last paired device *Reminding: Golden Rays, please ignore the pairing step, and the last paired device will be automatically connected after pairing.

Automatically connection
When the headphones are taken out of the charging case, it automatically connects to the last connected device which the Bluetooth pairing record if it is range.

Out of distance disconnection and reconnection
When the headphones are out of the Bluetooth connection range, they will lost Bluetooth effective range. The earpieces will be turned back to the last connected Bluetooth device automatically when they are back to the Bluetooth effective range and the charging case is open.

Tip: Due to the connection characteristics of Bluetooth signals, it is normal for the sound to be interrupted when the signal is weak, please adjust the connection distance between the devices.

Connection

Disconnect the current connected device
When it is range:
1.Put the two earpieces back into the charging case and keep the lids open.
2.Long press the function button on the charging case for 3 seconds until the indicator flashes red and blue alternately, then the headphones enter the pairing mode.

Factory Reset
1.Put the two earpieces into the charging case and keep the lids open.
2.Long press the function button on the charging case for 10 seconds until the indicator flashes red and blue alternately, then the headphones enter the pairing mode.
3.Turn on the Bluetooth function of your device and search for the Bluetooth headphones, then click the Bluetooth headphones to complete the pairing.
Tip: Due to the connection characteristics of Bluetooth signals, it is normal for the sound to be interrupted when the signal is weak, please adjust the connection distance between the devices.

Usage

Charging
Put the two earpieces in the charging case and it will automatically start charging.
Charging time: Approx. 1.5 hours, Standby time: Approx. 20h, the power light will be always on until the earpieces is fully charged.
Charging case: Approx. 3 hours, Standby time: Approx. 60h, the power light will be always on until the charging case is fully charged.
Tip: Please charge the earpieces and charging case for the first time or after long-term storage.

Charging case
Put the earpieces back into the charging case.
The charging case will automatically start charging.
Charging time: Approx. 3 hours, Standby time: Approx. 60h, the power light will be always on until the charging case is fully charged.

Power Indicator
When the earpieces are in the charging case, when the charging case is open, the power indicator will be always on.

Usage

Low battery alarm for charging case
When the charging case is low power, it will prompt you the low voltage battery alarm through both TWS earbuds.
When the charging case is low power, the two earpieces will be automatically shutdown and the charging case will be automatically shutdown after 30 minutes.

Tip:
The earpieces is in the charging case, when start the charging case power indicator will be always on until the charging case is fully charged.

Low battery alarm
When the two earpieces are in use, the right bud will prompt the low voltage battery alarm.

Tip:
The earpiece is in the charging case, when start the charging case power indicator will be always on until the charging case is fully charged.

Low battery alarm
In the left ear bud, only the right bud will prompt the low voltage battery alarm.

Tip:
The earpiece is in the charging case, when start the charging case power indicator will be always on until the charging case is fully charged.

Function

The function is turn on/ turn off by the touch sticks on the earbuds.

Function

Music
In the left ear bud, click the right bud twice to turn on/ off the music.

Call
Tap the touch stick on the left earbud to answer the incoming call.
Tap the touch stick on the right earbud to reject the incoming call.
Hang up: Click the left earbud twice.
Tip: When the two earpieces are in the charging case, keep the charging case open, the function of the earpieces will be disabled.

Function

Voice Assistant
Tap the touch stick on the right earbud for 1s to switch the mode
The prompt of voice assistant is on
Tap the touch stick on the right earbud for 1s to switch the mode
The prompt of voice assistant is off

Product Specifications

Model: HOLYSHANG Golden Rays
Bluetooth version: Bluetooth 5.0
Bluetooth Profile: A2DP,AVRCP,HFP,HSP
Bluetooth Range: 10m
Headphone Type: TWS
Headphone Function: Music, Call, Voice Assistant
Support system: Bluetooth device and mobile phone
Headphone Battery: 40mAh x 2 pcs, 3.7V
Charging case Battery: 500mAh, 3.7V
Battery capacity of earbuds: 3.7V 40mAh
Battery capacity of charging case: 3.7V 500mAh
Charging time: earbuds: 1.5h, charging case: 3h
Battery Life: earbuds: 20h, charging case: 60h

Please use the proper output charger that the device have which indicated in the manual.

Security Instructions

Please read this important security instructions before using the product. Failure to follow these instructions may result in injury to yourself and others or damage to the product or other property. Keep these instructions for future reference.

Warning
Do not use the unit safely earbuds and regulations should result in injury to yourself and others.
Do not use damaged power cord or plug or loose power socket.
Do not use damaged charger or cable.
Do not use the unit in a wet environment, such as the bathroom.
Do not use the unit near water, such as a swimming pool.
Long-term exposure to high volume may cause permanent hearing damage. Please use headphones at a reasonable volume.
Long-term exposure to high volume may cause permanent hearing damage. Please use headphones at a reasonable volume.
Do not put the device in the back pocket or hang it on the waist.
Long-term exposure to high volume may cause permanent hearing damage. Please use headphones at a reasonable volume.
Long-term exposure to high volume may cause permanent hearing damage. Please use headphones at a reasonable volume.
Long-term exposure to high volume may cause permanent hearing damage. Please use headphones at a reasonable volume.
Do not put the device in other electronic devices.
Do not use the unit near other electronic devices.
Do not use the unit near medical equipment.
Do not use the unit near flammable and explosive materials.
Do not use the unit near fire.
Do not use the unit near other electronic devices.
Do not use the unit near medical equipment.
Do not use the unit near flammable and explosive materials.
Do not use the unit near fire.
Long-term exposure to high volume may cause permanent hearing damage. Please use headphones at a reasonable volume.
Long-term exposure to high volume may cause permanent hearing damage. Please use headphones at a reasonable volume.
Do not use the device in a place where dust or vapor.
**Do not use the device in a place where dust or vapor