ANGEL ARMOR®

AVAIL®
BALLISTIC DOOR PANELS
NIJ LEVEL IIIA

INSTALLATION GUIDE

As shown on

NISSAN® PATROL FOR REAR DOORS
(2010 – 2016 MODELS)

NISSAN

COMPATIBLE WITH:

- **Nissan Armada** (2016 Models)
- **Infiniti® QX56** (2010 – 2016 Models)
- **Infiniti QX80** (2014 – 2016 Models)

MADE IN USA

angelarmor.com
970 235 2961
sales@angelarmor.com

101926_C

TABLE OF CONTENTS

INTRODUCTION 3

Product Description 3

Installation Overview 3

Warnings & Cautions 4

Legal Statements 4

TOOLS & PARTS LIST 5

Recommended Tools 5

Installation Kit Contents 6

INSTALLATION 7

Procedure 7

– Preparing for Installation 7

– Removing the Outer Window Weatherstrip 7–8

– Inserting the Ballistic Door Panel 8–9

– Replacing the Outer Window Weatherstrip and Completing Installation 10

REMOVAL OR DECOMMISSION 11

© 2026 ANGEL ARMOR, LLC. ALL RIGHTS RESERVED. PRINTED IN THE U.S.A.

NISSAN® IS A REGISTERED TRADEMARK OF NISSAN MOTOR CO. LTD

INTRODUCTION

Congratulations on your purchase of the Angel Armor® Avail® Ballistic Door Panel (Level IIIA) for Nissan Patrol (2010 - 2016) for rear doors. It's our honor to provide advanced protection to those who put their lives on the line in the name of law and order.

In just a matter of minutes, your vehicle will be upfitted with the finest ballistic technology available. With innovative ballistic materials, advanced designs and the fastest installation in the industry, Angel Armor Avail Ballistic Door Panels elevate protective technology to a higher level.



Figure 1. Angel Armor Avail Ballistic Door Panel (Level IIIA) for Nissan Patrol rear doors

Product Description

Angel Armor Avail Ballistic Door Panels (Level IIIA) are constructed of a proprietary technology that is not only remarkably strong, but also thin, lightweight and weatherproof. These properties, plus semi-rigid material characteristics, enable unprecedented ease of installation while providing protection independently tested in accordance with NIJ Standard 0108.01 protocol. Angel Armor Avail Ballistic Door Panels (Level IIIA) for Nissan Patrol exceed NIJ Standard 0108.01 protocol for multi-round protection and offer a five-year express limited warranty. Within this period, the panels may be removed and transferred to another vehicle of the same make and model without violating the warranty.

The Ballistic Door Panel installation shown in this Installation Guide was performed on the driver-side rear door of a 2016 Infiniti QX80. The installation process is the same for Nissan Patrol, Nissan Armada and Infiniti QX56 models.

Installation Overview

Angel Armor Avail Ballistic Door Panels (Level IIIA) for the Nissan Patrol require no additional brackets or fasteners, and eliminate the need to remove the interior door panel or window glass. The Ballistic Door Panel is inserted into the door, adjacent to the window glass. Door pry and pick tools are the only tools required.

Installation into a Nissan Patrol take as little as 90 seconds for experienced installers. The average user installation takes only 5 to 10 minutes.

Warnings and Cautions

Please adhere to the following guidelines to prevent personal injury, equipment damage and unnecessary difficulty during installation.

⚠ DISCONNECT THE VEHICLE BATTERY AFTER THE WINDOW IS ADJUSTED FOR INSTALLATION TO AVOID ACCIDENTAL AIRBAG DEPLOYMENT. ACCIDENTAL DEPLOYMENT OF THE AIRBAG MAY CAUSE SERIOUS PERSONAL INJURY.

⚠ Read this guide in its entirety before beginning installation.

⚠ Wear appropriate protective gear, including eye and foot protection.

⚠ Avoid excessive force when inserting the Ballistic Door Panel into the car door. Excessive force may damage the panel or internal door components.

⚠ Use only plastic trim removal/prying tools on finished surfaces to prevent scratching.

⚠ Discard and replace any door components that are inadvertently damaged during the installation process. Proper installation according to the instructions in this guide should not cause damage to any vehicle or Ballistic Door Panel parts or components.

⚠ Use caution when removing parts that may have sharp edges, such as the outer window weatherstrip.

Legal Statements

See Warranty and Terms and Conditions for important legal information. These instructions are provided for your convenience only, and Angel Armor expressly disclaims any liability for any damage to personal property or personal injury that occurs as a result of either installation or removal of panels.

TOOLS & PARTS LIST

This section lists the tools recommended for installation and the parts included in the installation kit.

Recommended Tools

- Pick Tools



Figure 2. Pick tools

- Plastic Door Pry Tools



Figure 3. Plastic door pry tools

Installation Kit Contents

- Angel Armor Avail Ballistic Door Panel (Level IIIA) for Nissan Patrol (2010 - 2016) Rear Doors

Figure 4. Angel Armor Avail Ballistic Door Panel (Level IIIA) for Nissan Patrol rear doors

- Angel Armor Brand Label

Figure 5. Angel Armor brand label

- Isopropyl Alcohol Wipe

Figure 6. Isopropyl alcohol wipe

INSTALLATION

This section provides instructions for installing Angel Ballistic Door Panel (Level IIIA) for Nissan Patrol (2010 - 2016) for rear doors.

Preparing for Installation

1 Lower the window glass completely.

2 Turn off the vehicle ignition switch, and remove the key.

3 ⚠ **Disconnect the vehicle battery to avoid accidental airbag deployment.**

Removing the Outer Window Weatherstrip

⚠ **Use caution when removing parts that may have sharp edges, such as the outer window weatherstrip.**

1 Using the door pry tools, carefully pry up on the inner weatherstrip to create a small gap in between the weatherstrip and the window frame.

2 Slide the pick tool along the inside of the weatherstrip until you locate the small hole holding the first retaining clip, about 2 – 2¼" from the back of weatherstrip.

▲ Figure 7. Inserting pick tool under lifted weatherstrip

3 Using the pick tool, gently release the first weatherstrip retaining clip.

▲ Figure 8. Releasing first weatherstrip retaining clip

Removing the Outer Window Weatherstrip
CONTINUED

4 Slide the pick tool along the inside of the weatherstrip until you locate the small hole holding the second retaining clip, about 2 – 2¼" from the front of weatherstrip. Using the pick tool, gently release the second weatherstrip retaining clip.



Figure 9. Releasing second weatherstrip retaining clip

5 Carefully pull up on the front portion of the outer window weatherstrip. Gently rotate the weatherstrip out and pull up on the trim to remove it from the window frame.

NOTE: BE CAREFUL, and **DO NOT** use excessive force when releasing the weatherstrip retaining clips. Excessive force will break the clips. The clips should release with ease if you follow these instructions.

Inserting the Ballistic Door Panel

1 Hold the Ballistic Door Panel so that its anti-abrasion panel faces the interior of the vehicle.

2 Leading with the bottom edge of the Ballistic Door Panel, begin to insert the panel into the door adjacent to the outer surface of the window glass.

NOTE: Hold the Ballistic Door Panel against the window glass as you insert to avoid obstructions inside the door. This can be achieved by lightly leaning back/pulling the panel out toward the exterior of the door.

Figure 10. Inserting panel into door

3 Once the Ballistic Door Panel is half-way installed, grip the top of the panel and push it away from you. This ensures the bottom of the panel is against the outer door skin.

Inserting the Ballistic Door Panel
CONTINUED

4 Using the Ballistic Door Panel, knock out the foam rubber spacers located inside of the door skin.

Figure 11. Knocking out foam rubber spacers

NOTE: The foam spacers need to be knocked out so the Ballistic Door Panel can clear the entire length of the door. The foam spacers can stay inside of the door skin; they will not cause damage or create any noise.

5 Slide the remainder of the Ballistic Door Panel down into the door, and push it down into its final location. Ensure that the panel is seated behind the crash bar.

NOTE: Work the Ballistic Door Panel down firmly to clear any obstructions, but never use excessive force. Excessive force may damage internal door components or puncture the Ballistic Door Panel's weatherproof cover. It may be useful to shimmy the panel side to side while pushing forward to move it into position.

6 Reconnect the vehicle battery.

7 Verify that the Ballistic Door Panel is properly positioned by confirming the following:

A. The nylon fold sits flush where the weatherstrip is installed.

Figure 12. Nylon sitting flush where weatherstrip is installed

B. The Ballistic Door Panel is seated behind the crash bar.

C. The window functions properly, rolling up and down with ease.

NOTE: If excessive nylon is exposed above the door and the crease does not align with the top edge of the window frame, remove the panel and repeat steps 1 through 7 of this section. Avoid tearing the Ballistic Door Panel's weatherproof cover on the "teeth" inside of the door by pushing the panel toward the back of the vehicle before lifting it out.

Replacing the Outer Window Weatherstrip and Completing Installation

1 Double-check that the retaining clips on the weatherstrip are not bent too far back. If so, use the pick tool to bend them in so they will engage properly.

2 Starting at the back of the door, line the back of the weatherstrip up with its corresponding slot in the window frame.

3 Press the back edge of the outer window weatherstrip on the metal edge of the window frame, and begin to seat the weatherstrip along the window frame.

Figure 13. Seating the weatherstrip

4 Verify that no nylon is exposed below or around the outer window weatherstrip.

5 Working from the back, press down to fully seat the entire length of the outer window weatherstrip onto the metal edge of the window frame.



Figure 14. Pressing down to fully seat the weatherstrip

6 Attach the Angel Armor brand label to the interior door panel by completing the following procedure:

A. Clean the attachment area on the door with the supplied isopropyl alcohol wipe.

B. Allow the door surface to dry completely.

C. Remove the backing from the brand label.

D. Apply the brand label to the door, pressing for at least 30 seconds to ensure proper adhesion.

Figure 15. Applying Angel Armor brand label

INSTALLATION COMPLETE:

Your vehicle is now equipped with advanced ballistic protection from Angel Armor.

REMOVAL OR DECOMMISSION

This section describes the process for removing the Ballistic Door Panel for decommission or transfer to another vehicle.

1. Lower the window glass completely.

2. ⚠ **Disconnect the vehicle battery to avoid accidental airbag deployment.**

3. Follow the procedure described in *Removing the Outer Window Weatherstrip* on pages 7-8.

4. Align the Ballistic Door Panel with the vertical window frame, and grip the nylon fold at the top edge of the ballistic panel.

   ⚠ **NOTE:** Avoid tearing the Ballistic Door Panel's weatherproof cover on the 'teeth' inside of the door by pushing the panel toward the back of the vehicle before lifting it out of the door.

5. Pull the ballistic panel straight up to remove it from the door completely.

6. Follow the procedure described in *Replacing the Outer Window Weatherstrip* on page 10.

7. If removing the Ballistic Door Panel for transfer to another vehicle, inspect the ballistic panel after removal. Contact Angel Armor with any concerns about wear or damage.