# LEOPARD ERV™ ILLUSTRATED PARTS LIST

Leopard ERV™ Post Mix Dispensing Valve

*PC board 750300426 is not available by itself. To purchase a new PC board, order Kit P/N 629097014.

Leopard ERV™ POST MIX DISPENSING VALVE

	Item No.	Part No.	Name	See Page No.
Components	1	620050825	Base Support	1
	2	620516639	Cover	1
	3	620715810	Diffuser Assembly	1
	4	620715815	Nozzle Outer with Overmold	1
	5	620050826	Lever Spring	1
	6	620716402	Back Block Retainer Clip	1
	7	60278110	Back Block (Includes Item #11)	1
	8	620050831	Lever Assembly- Metal	1
	9	620052472	Lever Switch Membrane Keypad	1
	10A	620313216	Keypad - Push with Water	1
	10B	620313217	Keypad – Push	1
	10C	620313219	Keypad – Water	1
	10D	620313220	Keypad - Portion with Water Pour/Cancel	1
	10E	620313221	Keypad - Portion Pour/Cancel	1
	10F	620313222	Keypad - Led Only	1
	11	180363000	O-ring, Back Block	1
	12	620315214	Water Module Assy.	1
	13	620315213	Syrup Module Assy.	1
	14	750300426	Printed Circuit Board	1
	15	620715714	Mixing Body Assy.	1
	16	750500518	Quad Ring (Qty. 2)	1
Accessories	19	319540000	Syrup Splitter	4
	20	70798	Back Block Tool	4
	21	325216000	Nozzle Brush	4
	22	620711625	Pocket PC - Setup device (No Longer Available)	4
	23	620316409	Pocket PC Interface Cable	4
	24	620711626	Tomcat - Setup device	4
	25	620314880	Syrup Flush Device	4
	26	620046544	PC Interface Cable	4
Valve Types	27	620607718	Base Valve (without activation method)	5
	28	620607724	Push Button	5
	29	620607728	Push Button with Water	5
	30	620607726	Portion Control with Pour/Cancel	5
	31	620607729	Water Only	5
	32	620607727	Portion Control with Pour/Cancel and Water	5
	33	620607725	Lever	5
	34	620607730	Lever with Water	5
	35	620609120	Base Valve with Back Block	5
Literature		620919579SER	Leopard ERV - Installation / Service Manual	Web Site
		620919579OPR	Leopard ERV - Operator's Manual	Web Site
		620920829	Pocket PC Operator's Manual	Web Site
		620920851INS	Tomcat Operator's Manual	Web Site
		620314880INS	Flush Device Installation Manual	Web Site
		TP01108	Approved Pocket PC Devices & Operating Systems	Web Site

	620049347	Troubleshooting Guide, Leopard	Web Site
	620049348	Syrup Module Installation Sheet, Leopard	Web Site
	620049349	Water Module Installation Sheet, Leopard	Web Site
	620049350	PCB Installation Sheet, Leopard	Web Site
	620049352	Lever Installation Sheet, Leopard	Web Site
	620049353	Keypad Installation Sheet, Leopard	Web Site
	620049354	Mixing Body Installation Sheet, Leopard	Web Site
	620049355	Base Installation Sheet, Leopard	Web Site

Kits	36	629097012	Syrup Module Kit, Leopard	
	37	629097013	Water Module Kit, Leopard	
		629097014	PCB Kit, Leopard	
	38	629087584	Nozzle Kit, Leopard	
	39	620050893	Wire Harness Leopard Keypad	

ACCESSORIES

19 - Syrup Splitter

20 - Back Block Tool

21 - Nozzle Brush

22 - Pocket PC Setup Device

23 - Pocket PC Interface Cable

24 - Tomcat Setup Device

25- Syrup Flush Device

26 - PC Interface Cable

VALVE TYPES

**27 - Base Valve**

28 - Push Button

**29 - Push Button with Water**

**30 - Portion Control with Pour/Cancel**


31 - Water Only

32 - Portion Control with Pour/Cancel and Water

33 - Lever

34 - Lever with Water

35 - Base Valve with Back Block

To inquire about current revisions of this and other documentation or for assistance with any Cornelius product contact:

www.cornelius.com
800-238-3600