



**Read
Before
Use**

As a precaution, gloves and eye protection should be worn when handling substances and using test units. Do not puncture any part of unit. Do not remove probe once a capsule is broken. In the unlikely event of a spill, rinse affected area thoroughly with water. Keep out of reach of children. All results are presumptive.

Test Preparation	1	Remove the probe from test unit.	Sample suspected substance.		
			Touch or Swipe or Dip	Touch probe to the suspected substance.	Swipe either side of the probe across the suspect substance.

Test Preparation	3	Secure probe into test unit. Press firmly.	Identification	4	From both sides of the kit, squeeze on the circle of Chamber 1 until the capsule breaks.	5	Gently shake test unit for 2-3 seconds.

STOP
Do not continue unless probe is secured properly in place.

Identification	6	From both sides of the kit, squeeze on the circle of Chamber 2 until the capsule breaks.	7	Gently shake test unit for 2-3 seconds.

Results		The appearance of an orange or yellow color indicates the presence of Peroxide .
		If an orange or yellow color develops, proceed to Disposal. If no orange or yellow color develops, proceed to Step 8.

Chamber 3 Identification	8	From both sides of the kit, squeeze on the circle of Chamber 3 until the capsule breaks.	9	Gently shake test unit for 10 seconds.

Chamber 3 Results		The appearance of an orange or yellow color indicates the presence of TATP or HMTD .
		If no orange or yellow color develops, the above listed substances are not present.



Disposal

After Dilution, the test kit is safe to dispose of in the trash.