



**Read
Before
Use**

As a precaution, gloves and eye protection should be worn when handling substances and using test units. If a spill occurs, thoroughly rinse affected area with water. Keep out of reach of children. Store the bottle in a dark place, not exposed to light. All results are presumptive.

Step	Unit	Illustration	Directions
Sample Material			Remove a sheet of test paper from the pad. Wipe the test paper across the suspected substance or surface.

Testing Procedure (Yellow Cap)			Open and remove the cap from the Yellow Cap bottle. Apply a drop to the test paper.
---	--	--	---

	Color	Description	Substance Indicated
RESULTS		Orange or Yellow	Indicates TATP, HMTD or Peroxide