PULSE IV SYSTEM

(AM3200 SERIES 3)



www.amcad-mw.com

SYSTEMS CATEGORY : STANDARD

- Compact and efficient design
- Embedded power supplies
- Flexible and upgradable
- Unrivaled measurement resolution and accuracy High reliability pulse generators
- Driven by IVCAD Software



MAIN FEATURES :

- **Reliable pulsers** with long-lasting performances (thermal, SOA and **DUT** breakdown protections).
- Pulsed or DC operation, pulse width down to 200ns from the generators.
- Internal or external synchronization for precise control.
- Extended stop conditions and built-in protection for enhanced safety.
- **Mix-and-match** input and output pulsers for flexible configurations.
- Connect systems in series for synchronizing **3**+ pulsed channels with high accuracy.
- Long pulses into the tens of seconds for trapping and thermal characterization.
- **Direct hardware programmability** for seamless integration.



System description

This Pulse IV system is used to bias transistors in quasi-isothermal conditions, enabling accurate compact modeling activities.



Pulser Safe Operating Area

Emergency stop when the operating point exceeds design limits: lp, Irms, Idc (pulsed, RMS, and DC current), Vdc (pulser input voltage, drain pulser only), Pmax (DC power), Fmax (switching frequency), Temperature.

Current Breaker

Programmable thresholds: pulse current and power, quiescent current and power, transient current.


Measurement Sampling Time

Programmable thresholds: pulse current and power, quiescent current and power, transient current.

Modularity

ΛΜCΛD

The standard system works with two pulse generators and one control box. External signals permit to combine and synchronize several control boxes (4, 6, 8...).



4 Pulsed IV System - Brochure

Thisdocument may not be reproduced, modified, adapted, published, translated, in anyway, in whole or in part, or disclosed to a third party without the prior written consent of AMCAD SAS @ Amcad 2025


AM3211 BIPOLAR PROBE ±25V / ±1A :

The AM3211 is a low-noise floating pulse generator dedicated to bias the transistor gate, optimized to drive quickly and safely all transistors (RF Devices, MOSFET).



AM3221 PROBE +250V / +30A :

The AM3221 probe is a power probe dedicated to bias the transistor drain, optimized for highpower pulsed measurements.




5 Pulsed IV System- Brochure

SYSTEM SPECIFICATIONS

CONTROL BOX AM3200 SYSTEM		
PULSERS	AM3211	AM3221
PURPOSE	GATE	DRAIN
OPERATING RANGE		
Switched voltage levels	2	2
Voltage	±25V	+250V
Pulsed current	±1A	+30A
DC & RMS Current	±300mA	+5A
DC power	3W Source, 0.5W Sink	100W
Pulse Power	10W Source or Sink	3KW
SOURCE PERFORMANCE		
Voltage setting resolution	16bit	18bit
Output impedance	l≤0.1mA: 204Ω / I> 0.1mA: 14.5Ω	I≤0.3A: 2Ω / I>0.3A: 0.4Ω
PULSE TIMING		
Rise Time (10% - 90%)	fast(*): 33ns (typ. value)	fast(**): 20ns (typ. value)
Fall Time (10% - 90%)	fast(*): 32ns (typ. value)	fast(**): 22ns (typ. value)
Pulse timing	Resolution: 20ns, Width: 200ns to DC (Power limits)	
Fmax	500kHz	
MEASUREMENT PERFORMANCE		
Vrange	25V	250V/5V
Irange	1A/10mA/0.1mA	30A/3A/0.3A
V & I ADC resolution	16bit	16bit
Noise free resolution (average filter 128 samples, at 0 voltage and current)	0.5mV	3mV/0.25mV
Settlingtime	300ns	300ns
Bandwidth (greatest range)	10MHz	10MHz
Output connector	D-SUB15	2 BNC

*: AM3211, speed : fast, no load, 5V step **: AM3221, speed : fast, no load, 100V step


ΛΜCΛD



Thisdocument may not be reproduced, modified, adapted, published, translated, in any way, in whole or in part, or disclosed to a third party without the prior written consent of AMCADSAS © Amcad 2025


AM3211 Bipolar Probe +/-25V+/-1A


Example of pulsed voltages provided by the AM3211 bipolar probe



Load=open, -5V -> +5V

Load=5W, OV +5V at 1A





Load=open, OV -> -5V

Voltage Pulse Shape measured with an Oscilloscope (Keysight DSO-X, 4054A & 700MHz Voltage probe N2894A)




7 Pulsed IV System- Brochure

This document may not be reproduced, modified, adapted, published, translated, in anyway, in whole or in part, or disclosed to a third party without the prior written consent of AMCADSAS @ Amcad 2025

AM3221 Bipolar Probe +250V+30A


Example of pulsed voltages provided by the AM3211 bipolar probe




Load=open, 0V -> +50V



Load=5W, 0V -> +10V at 2A





Load=open, 250V -> 0V


Voltage Pulse Shape measured with an Oscilloscope (Keysight DSO-X, 4054A & 700MHz Voltage probe N2894A)



8 Pulsed IV System- Brochure

This document may not be reproduced, modified, adapted, published, translated, in anyway, in whole or in part, or disclosed to a third party without the prior written consent of AMCAD SAS @ Amcad 2025

Ultimate Measurement Speed and Performances





nt may not be reproduced, modified, adapted, published, translated, in anyway, in whole or in part, or disclosed to a third party without the prior written consent of AMCADSAS @ Amcad 2025

Warranty

Any AMCAD product comes with a two-year parts and labor warranty, when returned to our workshops. A phone support service is also available for the same period.

At the end of the initial two-year period, a further contract can be subscribed, including:

- a preventive functional check and calibration of the modules (onsite or in our workshop)
- a further two-year warranty period

Quality Regulations & Environment


The PIV System and all modules are compliant to the applicable European directive and hold the CE mark.

- ISO/CEI 17025 compliant calibration for

 any DC source or measurement module, calibration certificate provided.
- Serial number based life cycle management
- All products are 100% tested (test reports on demand)
- AMCAD only uses RoHS compliant components and does not use substances banned by the COSHH regulation.
- AMCAD complies with the relevant national regulations related to the safety and health of its employees against hazardous substances.
 - The protection degree of the PIV system is IP20 according to CEI 60529.

Probe dimension (mm)

ΛΜϹΛΟ



10 Pulsed IV System - Brochure

Thisdocument may not be reproduced, modified, adapted, published, translated, in any way, in whole or in part, or disclosed to a third party without the prior written consent of AMCAD SAS @ Amcad 2025

CONTACT US



www.amcad-mw.com

Bâtiment Galiléo | 20 rue d'Atlantis, 87068 Limoges FRANCE

Email: sales@amcad-mw.com

Phone: +33 5 47 74 42 30

This document may not be reproduced, modified, adapted, published, translated, in any way, in whole or in part, or disclosed to a third party without the prior written consent of AMCAD SAS © Amcad 2025

11 | Pulsed IV System - Brochure