

Error codes

- **Error message 201/202**

The pressure during vacuuming of the measurement space does not reach a set value within a set time.

Cause:

1. Pack leak / Big hole or
2. Membrane has a leak

- **Big leak (error message in logfile 101 or error 102)**

The measurement is checked and is above a set value.

Cause:

1. Big hole in the pack or
2. Membrane has a leak

- **Error 203**

Main valve did not function properly.

➤ Contact Oxipack support

- **Sensor error**

Sensor has no signal.

➤ Contact Oxipack support

- **Air pressure below 4 bar**

Please verify incoming pressure and follow instructions on the display. Once the feed pressure reached the correct value, instructions will appear.