



**ED250 PRO GATE/ED300 - Daily Cleaning Procedure - Clean/Sanitize Valves**

*Supplies*

**Equipment Needed**

- Two Clean blue towels
- Sanitizer bin, Vollrath # 9728001
- Nylon nozzle brush

**Products Needed**

- K Chemicals  
Sanitizing Solution (KAY Sink Sanitizer)

**WARNING: DISCONNECT POWER BEFORE CLEANING! DO NOT USE SOLVENTS OR OTHER CLEANING AGENTS, AS THEY MAY ATTACK THE PLASTIC/METAL.**

Step	Action	Photo
1.	Wash and sanitize hands.	
2.	Remove the nozzle from the dispenser by turning and pulling down.	
3.	Remove the diffuser from the valve by pulling down. Place the nozzle and diffuser into the sanitizer bin filled with sanitizer from the 3rd compartment. Make sure sanitizer solution reads between 100-200 PPM.	

4.	Wipe inside the diffuser area using a sanitized blue towel and the nylon nozzle brush.	
5.	Clean the diffuser and nozzle using the nylon nozzle brush. Rinse with lukewarm water in the 2nd compartment and sanitize in the 3rd compartment.	
6.	Reinstall the diffuser and nozzle. Ensure they are located correctly in the machine.	