Injector Inspection and Service

Asset Tag	Maintenance Location	Date
		1/2/2026

Employee Name (Print)	Employee Name (Sign)

			Checked
Before beginning service, check for Gladiator/OEM recalls and maintenance / safety bulletins to be added to inspection			✓
	Weekly	Value	UOM
1	Record Injector Hubometer Footage	1,541	ft
2	Check hoses and fittings for leaks, damage or wear	✓	Check
3	Clean drive chain and grippers and check for dirt, debris, damage or wear. Lubricate the drive chain	✓	Check
4	Check that gripper elastomers are not worn or damaged and quick connect spring is in working order.	✓	Check
5	Check tension cylinder gap is > 1/8"	N/A	in
6	Check gooseneck rollers, latches, cylinders for damage or wear, grease rollers	✓	Check
7	Check lifting shackles and slings for wear or damage and current certification	✓	Check
8	Check sprockets for damage or wear	✓	Check
9	Check traction and tension cylinders for function, wear, corrosion, or leakage	✓	Check
10	Check load cell for leakage, adjustment, damage and tie-down bolts move freely	✓	Check
11	Check Encoder and camera for damage.	✓	Check
12	Check connection plate and cables for damage. Connections are to be clean and caps installed.	✓	Check
13	Check gearbox lubricant	✓	Check
14	Check frame and base for damage	✓	Check
15	Grease gear drive bearings	N/A	Check
16	Grease idler sprocket bearings	✓	Check
17	Change high pressure filters	✓	Check
18	Perform injector brake test	✓	Check

Note all deficiencies below

Gooseneck twisted at the arch not the fan. Change front gearbox oil. Replace all gearbox seals on both drives,

Inspect top section bearings, replace 1 timing hose, Chains at only 1% streatch

All blocks are still in tollerence

Reference NOV Injector Owner's Manual for specific work and maintenance instructions.