

# 2011- 2014 DURAMAX LML EGRUPGRADEKIT



Installation Manual

## WARNING REGARDING EMISSIONS LAWS

Not legal for sale or use on pollution-controlled motor vehicles anywhere in the United States. Legal ONLY for off-road competition racing vehicles and cannot be used on vehicles that are operated on public streets, roads, or highways.

## DISCLAIMER

- 1) By installing this product onto your vehicle, you assume all risk and liability associated with its use.
- 2) It is your responsibility to make sure your vehicle complies with all federal, state, and local emissions laws. Federal and many state and local laws prohibit the removal, modification or rendering inoperative of any part of the design affecting emissions or safety on motor vehicles used on a public street or highway. Violation may result in a fine of up to \$32,500 per vehicle (or possibly higher depending on changes in the law). All civil penalties and fines for removing your vehicle's emissions equipment are the sole responsibility of the end user.
- 3) Due to its high performance nature, this product may void vehicle manufacturer's warranty.
- 4) GDP Tuning, LLC. is not responsible for misuse of its products. By installing this product, you release GDP Tuning, LLC. of any and all liability associated with its use.
- 5) Depending on where you live, restrictions may apply. Check all applicable laws before installing or using!
- 6) The purchaser and end user releases, indemnifies, discharges and holds harmless GDP Tuning, LLC. from any and all claims, damages, causes of action, injuries, or expenses resulting from or relating to the use or installation of this product that is in violation of the terms and conditions on this page, the product disclaimer, and/or the product installation instructions. GDP Tuning, LLC. will not be liable for any direct, indirect, consequential, exemplary, punitive, statutory, or incidental damages or fines caused by the use or installation of this product.

Step 40: Install the plastic intercooler tubing. Remember that the intercooler tube has a twist lock connection at the throttle valve. (Image 28)



IMAGE 28

Step 41: Reconnect the electrical plug into the throttle valve, and attach all the electrical connectors to the plastic intercooler tube.



IMAGE 29

Step 42: Reinstall the PCV valve on the back side of the plastic turbo mouthpiece. (Image 29)

Step 43: Reinstall the intake tube, air box and air filter, and reconnect the MAF sensor. (Image 30)



IMAGE 30

Step 44: Reinstall the intake resonator on top of the plastic turbo mouthpiece.

Step 45: Reconnect the batteries and refill the coolant per factory specifications.

Step 46: Start the engine, and let it run for a few minutes. Check for any leaks, and add coolant if necessary. Note: Check coolant after driving, add coolant as necessary.

Step 34: Install the new blue billet aluminum intake block off plate. This will be installed where the EGR valve was removed (see steps 18 and 19). (Image 25)



IMAGE 25

Step 35: Reinstall the intake tube, securing it in place with the two original bolts.



IMAGE 26

Step 36: With the original hardware, install the two brackets and the electrical connector to the intake tube. (Image 26)

Step 37: With the original hardware, secure the dipstick to the intake tube.



IMAGE 27

Step 38: Reinstall the grid heater and the throttle valve. This can be done simultaneously (Note: There should be a total of five bolts to secure the grid heater and throttle valve in place). (Image 27)

Step 39: Connect the red power wire under the plastic cover on the side of the grid heater, and reconnect the green electrical connector on the back of the grid heater.

## CAUTION!!!

Never work on a hot vehicle. Serious injury in the form of burns can result if the vehicle has been in use. Allow vehicle to cool prior to installation. Always wear eye protection when working on or under any vehicle.

Note: With a used vehicle, we suggest using a penetrating spray lubricant to be applied liberally to all exhaust fasteners. When doing so allow a significant amount of time for the chemical to lubricate the threads before attempting to disassemble.

Step 1: Disconnect the negative battery cables from both batteries.



IMAGE 1

Step 2: Drain the engine coolant by removing the metal retaining clip on the lower radiator line and pulling the line away from the radiator enough to allow the coolant to flow out. As the flow of the coolant slows down and the overflow bottle is empty, reconnect the lower radiator line. (Image 1)



IMAGE 2

Step 3: Remove the intake resonator that is held in place by two bolts. (Image 2)

Step 4: Loosen the hose clamps on the intake, and

disconnect the  
MAF sensor.  
(Image 3)

Step 5: Remove the intake  
tube, air box, and air filter  
from the vehicle.

Step 6: Remove the electrical  
connectors on the plastic  
intercooler tubing and the  
electrical connector on the  
throttle valve.

Step 7: Remove the plastic  
intercooler tube from the  
throttle valve. The intercooler  
tube has a twist lock  
connection at the throttle  
valve.  
(Image 4)

Step 8: Remove the green  
electrical connector from  
the back of the grid heater.  
(Image 5)

Step 9: Remove the plastic  
cover on the side of the grid  
heater, and remove the red  
power wire.  
(Image 6)

Step 10: Remove the throttle  
valve that is held in place by  
four bolts attaching it to the  
grid heater.



IMAGE 3



IMAGE 4



IMAGE 5



IMAGE 6

front coolant line near the  
thermostat. Using one of  
the larger hose clamps, install  
the barbed fitting into the  
front coolant line, which was  
previously attached to the  
front EGR cooler.  
(Image 21)



IMAGE 21

Step 31: Using the last large  
hose clamp, install the loose  
end of the 3/8" coolant line  
into the heater hose running  
into the rewall.  
(Image 22)



IMAGE 22

Step 32: Using the smaller  
hose clamp, install the  
coolant line that previously  
ran to the exhaust bypass  
valve on the last open port  
on the new coolant line.  
(Image 23)



IMAGE 23

Step 33: Reinstall the plastic  
turbo mouthpiece to the turbo  
using the factory  
V-band clamp.  
(Image 24)



IMAGE 24



nuts that connect the up-pipe to the exhaust bypass valve. Remove the bolt on the backside of the exhaust bypass valve that is securing the coolant line.

Step 27: Remove the exhaust bypass valve that is now held in place by two vertical bolts. (Image 18)

Step 28: With the exhaust bypass valve removed, install the new exhaust block o using the factory gasket and the supplied hardware. Four M8 x 25 hex head bolts will bolt in from the back, and one M10 x 20 hex head bolt will hold the bracket in place. (Image 19)

Step 29: Using one of the larger hose clamps, install the new 5/8" coolant line into the existing return line. The existing return line runs down behind the turbo. The free end of the larger blue tee will be installed directly into the return line. (Image 20)

Step 30: With the 5/8" coolant line in place, route the 3/8" coolant line with the brass barbed fitting to the



IMAGE 18



IMAGE 19



IMAGE 20

(Image 7)

Step 11: Remove the one remaining bolt that holds the grid heater to the intake tube. (Image 8)

Step 12: Remove the two bolts securing the dipstick to the intake tube. Remove the plastic clip holding the wireway to the front of the intake tube.

Step 13: Remove the two brackets secured to the intake tube, and remove the electrical connector on top of the intake tube. (Image 9)

Step 14: Remove the intake tube that is held in place by two bolts. (Image 10)

Note: It is important to plug the intake port with a clean rag to avoid any debris from getting into the intake system.

Step 15: Remove the two bolts holding the PCV valve in place on the back side of the plastic turbo mouthpiece. Move the PCV and mounting bracket safely out of the



IMAGE 7



IMAGE 8



IMAGE 9



IMAGE 10

way. (Image 11)

Step 16: Loosen the V-band clamp that secures the plastic turbo mouthpiece to the turbo. Remove the mouthpiece from the



IMAGE 11

Step 17: Remove the crossover tube, that is held in place by ve bolts. There will be two bolts on either end of the tube and a single bolt (circled in Image 12) securing the crossover tube in place. (Image 12)



IMAGE 12

Step 18: Remove the four remaining bolts securing the EGR valve in place. (Image 13)



IMAGE 13

Step 19: Remove the electrical connector from the EGR valve and remove the EGR valve from the vehicle.

Step 20: Remove all ve of the coolant lines (four of which can be seen in Image 14) running to the EGR coolers. It is important to remove the coolant line running between the two coolers as well. (Image 14)



IMAGE 14

Step 21: Remove the four bolts connecting the two EGR coolers together. (Two of which are circled in Image 14)



IMAGE 15

Step 22: Remove the front EGR cooler that is now held in place by two vertical bolts on the front side of the EGR cooler.



IMAGE 16

Step 23: Remove the four bolts securing the second EGR cooler to the exhaust bypass valve. (Image 15)

Step 24: Remove the second EGR cooler that is now held in place by a single vertical bolt near the front of the cooler. (Image 16)



IMAGE 17

Step 25: Remove the two coolant lines that are running to the exhaust bypass valve. The line running to the EGR cooler will be completely removed from the vehicle. The second line will only be removed from the coolant port on the exhaust bypass valve. (Image 17)

Step 26: Remove the three