



## Quick Reference Guide to Your Smoke Alarm

### 1. Property maintenance measures

Your smoke alarm was installed by and belongs to the property. It is the property's responsibility to ensure its operational readiness. This is done remotely once a year, which means no one will visit the premises during testing.

The smoke alarm's battery lasts for 10 years and does not need to be replaced.



### 2. Testing the smoke alarm

It is the resident's responsibility to test the operation of the smoke alarm regularly (monthly) using the TEST/MUTE button.

On the 16th of each month, the smoke alarm automatically tests the alarm function and emits a short clicking sound.



### 3. Instructions when the smoke alarm is sounding or beeping

1. Check to see whether the alarm was caused by a fire. If you detect a fire, act in accordance with the instructions of your property's rescue plan.

This is how to mute your smoke alarm:

2. If the smoke alarm sounds by mistake, press the TEST/MUTE button. The smoke alarm will stop sounding for 10 minutes.

3. If the smoke alarm sounds because of a defect in the battery (sounds once every 48 seconds), press the TEST/MUTE button. The smoke alarm will stop sounding for 12 hours. Notify the responsible party for your property that the smoke alarm needs repair.

4. If the smoke alarm reports a defect (sounds twice every 48 seconds), press the TEST/MUTE button. The smoke alarm will stop sounding for 12 hours. Notify the responsible party for your property that the smoke alarm needs repair.



**It is the resident's responsibility to notify the responsible parties for the property of defective smoke alarms.** Contact the property's responsible parties or customer service at the Safetum Call Center. The property is in charge of operational readiness for your smoke alarms as well as repairs. The resident is not allowed to remove the smoke detector from the ceiling.

#### Please scan the QR code!

Download the smoke alarm instructions in different languages:

