

I'm not a robot



Britax marathon instruction manual

Britax marathon specs. Britax marathon clicktight instructions. Britax marathon clicktight washing instructions. Britax marathon instructions. Britax marathon washing instructions.

This booklet is the User Guide for the Page 1 Marathon child restraint. Table of Contents include Safety Information, Child Restraint Features and more. Safety first! The American Academy of Pediatrics says rear-facing till at least one year old or 20 pounds. Use this restraint with kids between 5-65 pounds and under 49 inches tall. Snug the belts tight so they don't sag or press on your child's skin. Important safety tips: Don't use a six-year-old or severely crashed child restraint. The safest place for a child restraint is in the back seat, according to crash statistics. Register this restraint to get recall info and keep it safe from direct sunlight and heavy objects. Remember: Adjust the harness each time you use it. Cover it when parked in the sun, store it safely, don't leave kids alone in it, and never disassemble or alter parts of the child restraint. Keep loose objects out of the back seat too! The child restraint has several features, including Harness Slots, Comfort Pads, a Chest Clip, Harness Holders, HUGS Shoulder Pads, and more. Each compatibility chart. This child restraint is only compatible with vehicle belts that have specific characteristics. Certain types of vehicle belts, such as from hybrid or top-of-the-line cars, are not compatible. Check your owner's manual to determine the type of belt in your vehicle. Installation: The restraint must be installed in a forward-facing vehicle seat. Side-facing or rear-facing seats cannot be used. For LATCH installation, verify that the vehicle is equipped with LATCH anchors and remove them from storage pouches if necessary. Push the child restraint firmly into the vehicle seat while tightening each LATCH harness. Note: The back angle of the child restraint should not exceed 45° when properly installed in the rear-facing position, and the recline angle can be adjusted using the Versa-Tether. Store the LATCH connectors in storage pouches above the rear-facing lock-offs when not in use. Specific installation instructions for rear-facing lap-shoulder belt and lap belt installations are provided, including proper positioning of the child restraint, passing the vehicle belt through the first rear-facing belt slot, and locking off the belt to prevent breakage. 1. Place the child restraint forward-facing on the vehicle seat. 2. Adjust the buckle until you hear a click 3. Pull the belt out and lock off arm away from your body 4. Kneel down and guide it into place, make sure everything is snug About using Versa-Tether before traveling. Important safety note: only attach Versa-Tether to designated tether anchors in your vehicle, as specified by the manufacturer. Do not use other locations, as this is not approved or permitted. Britax recommends always using the tether for improved stability and reduced risk of injury. If your vehicle doesn't have a tether anchor attachment, refer to the owner's manual or contact the manufacturer for assistance. If a tether anchorage isn't available, do not modify the vehicle without consulting the manufacturer. Do not attach Versa-Tether to the bottom of the vehicle. Instead, hook it to an anchor point (see figure A for forward-facing installation and figure B for rear-facing installation). For rear-facing installation, you may also need to use the Tether Connector Strap, as described on page 25. Pull the adjuster strap to remove all slack, then verify that there is tension in the tether strap and the child restraint is properly secured. Note that the rear-facing recline angle of the child restraint should not exceed 45° from vertical. If you need to use the Rear-Facing Tether Connector Strap, only attach it as described on page 27. The tether has been designed to indicate when the child restraint has been in a severe crash and replacement is necessary. Important: If the child restraint has been in a severe crash, discontinue use and contact Britax Child Safety, Inc. Consumer Services for further instruction. Additionally, be aware of the buckle position as it can affect the stability of the child restraint. In an accident, an improperly positioned buckle could become loose and the child would be unprotected. If the buckle lies near the wrong position () when the vehicle belt is tightened, try fitting the child restraint in another seating position in the vehicle. Securing your child in a Buckle child restraint involves several steps. First, fasten the Chest Clip by clicking it into place. Then, loosen the harness and pull the shoulder straps forward. Next, unfasten the chest clip and unbuckle the harness. Move the harness straps to the side of the restraint and use the harness holder to keep them in place. Tighten the lap section of the harness by pulling up on the straps, then adjust the harness around the child by pulling the adjuster strap. Ensure a snug fit without any slack or unnatural positioning. To check the harness height, place your child in the restraint and secure the harness. Observe where the shoulder harness is positioned on the child's body. For rear-facing use, the harness straps should be located at or below the child's shoulder. For forward-facing use, they should be at or above the child's shoulder. If you need to adjust the harness height, loosen the harness and pull the shoulder straps forward. Unhook the shoulder harness from the yoke and pull the straps through the shell and cover. For maintenance and cleaning, remove the upper portion of the cover by loosening the harness and pulling the upper harness straps through the shell and cover. Remove the belly pad and gently take out the lower harness straps, buckle tongues, chest clip, and buckle through the slots in the cover. Never attempt to take apart the harness or remove the buckle tongues. To clean the cover, hand wash it with cold water and mild soap. Line dry to prevent shrinkage. The shell can be sponge cleaned with warm water and mild soap. DO NOT: Use harsh chemicals, abrasive cleaners, or disassemble the harness. Cleaning the Harness SOFTEN WITH WARM WATER AND MILD SOAP. TOWEL DRY. Avoid using bleach, machine washing, machine drying, or disassembling the harness. Cleaning the Harness ADJUSTER AREA Check periodically to ensure it's clean and free of debris, food, coins, dirt, and other objects. Remove any debris to prevent interference with the adjuster mechanism. Page 36 Care and Maintenance Buckle Removal RECLINE THE CHILD RESTRAINT FULLY. Locate the metal buckle strap retainer on the bottom of the restraint. Pull away from the child restraint to loosen, then turn to pass through the shell's slot (Fig. A). Push the retainer through slots in the shell and cover to the front of the restraint. Care and Maintenance Cleaning the Buckle CHECK AND CLEAN THE BUCKLE Periodically remove any accumulated debris or dried liquids that may have formed due to eating or drinking while in the restraint. RINSE THOROUGHLY WITH WARM WATER (Fig. B). SOAK OVERNIGHT IF POSSIBLE, then rinse with warm water to loosen hardened drinks or food. TEST THE BUCKLE by fastening and unfastening until a positive click is heard after inserting the second buckle tongue (Fig. C). If no click is heard, repeat the cleaning procedure. Some states may not allow limitations on implied warranties or exclude incidental or consequential damages, so these limitations may not apply. This warranty provides specific legal rights, which vary from state to state. Neither Britax nor the retailer selling this product authorizes anyone to create a different warranty or liability in connection with this product.