

Continue



Viva water dispenser manual 8liech-sc-ssd

Viva self clean water dispenser manual. Viva water dispenser not working. Why is my water dispenser so slow. Viva self clean water dispenser not working. Viva water dispenser manual.

Ask publishers to restore access to over half a million books. at least four inches space on both sides for safe installation. 4. attach Wall Mount Strap to avoid accidental tipping; • release strap from back of dispenser, then install the correct bottle holder by following these steps: If your water bottle looks like the model that comes with a Probe Receptacle (1), no changes are required and the Probe will push the Plug out when you put the bottle in. If your water bottle has 3 or 5 gallon capacity, use only this type of bottle. Do not use for other liquids or purposes. warranty void if used for anything else. wait at least four hours before using with compressor facing up to avoid damage. remove tamper seal from bottle cap but do not remove plastic cap. clean the dispenser and cabinet surfaces as needed with soft cloth and warm soapy water. wipe dust from back of dispenser to improve efficiency. remove drip tray assembly and wash in dishwasher or with soap and water. if dispenser doesn't work, check power cord connection. for leaks or stuck buttons, call 855-VIVA-111 for assistance. make sure bottle is not empty and push controls fully. replace bottle receptacle if no water comes out.Limited Warranty: Vendor warrants the original purchaser that all parts shall be free from defects in material and workmanship for one year from date of purchase. 1. Installing Wall Mount Strap - Use a Philips screwdriver and secure the strap by installing the screw through the washer, then the eyelet in the strap and into the wall-mounted anchor. - Clip the strap onto the back of the cooler to the right or left side, adjusting the length so it cannot move forward. 2. Installing Bottle Receptacle - Remove the bottle receptacle by turning it counter-clockwise and pulling up. - Remove the collar from the foam packaging or bag at the front of the dispenser. - Align the tabs on the receptacle with the corresponding markings on the cooler, then secure it clockwise. 3. Operating the Dispenser - The unit is designed for water dispensing only; do not use other liquids. - Ensure the unit is filled with a 3- or 5-gallon capacity bottle and that the tamper seal is removed from the bottle cap. - Plug the cord into a properly grounded wall outlet, then turn the energy-saving switch to ON to heat the water. - To dispense cold water, position the bottle securely below the tap, depress the cold water control downward, and release it once the desired fill level is achieved. For Assistance: Proper Care & Cleaning General Cleaning: - Perform as needed (5 minutes) - Use soft cloth and warm soapy water; do not use abrasive materials or chemical cleaners. - Clean cabinet surfaces, wipe dust from back of dispenser, remove drip tray assembly, clean parts, and put them in dishwasher or wash with soft cloth. Cold Reservoir and Water Lines Cleaning: - Perform every 3 months or when off-taste occurs (15 minutes) - Turn energy saving switch OFF, unplug power cord, remove water bottle, unclip Wall Mount Strap, and turn dispenser around. - Place bucket under drain plug; remove drain cap and silicon plug. Avoid direct contact with hot water. Keep children and pets away. Troubleshooting: - Dispenser does not operate: ensure proper connection to working outlet. - Water is leaking: call 855-VIVA-111 for assistance. - Push buttons are stuck or faucets are leaking: apply mineral oil (baby oil) to button slides. - No water from taps: ensure bottle is not empty, push controls fully, and remove/reinsert bottle receptacle. Cold water not cold? Adjust thermostat and wait one hour. Hot water not hot? Ensure power cord connection and energy saving switch ON. Dispenser noisy? Position on level surface. Bad-tasting water? Drain reservoirs, replace bottle with a fresh one, and clean dispenser according to Proper Care & Cleaning instructions. Limited Warranty: - Electrolamp Technologies Inc. ("Vendor") warrants this dispenser to the original purchaser. - Vendor will repair or replace defective parts at no additional cost. The dispenser is assembled and operated according to the printed instructions provided, and for a period of one year from the date of purchase, all parts in the dispenser are guaranteed to be free from defects in material and workmanship. To make a warranty claim, you may need to provide proof of your date of purchase, so it's recommended that you keep your sales slip or invoice as proof. The Limited Warranty covers repair or replacement of defective parts, which must be returned to the Vendor's Customer Service Department for examination. If a defect is confirmed and approved, the vendor will replace the part without charge. However, this warranty does not cover damages or operating difficulties caused by accident, abuse, misuse, alteration, misapplication, improper installation, or lack of maintenance. Additionally, this warranty does not cover damages to the finish, such as scratches, dents, discoloration, or rust, after purchase. After one year from the date of purchase, all implied warranties, including those for merchantability and fitness for a particular purpose, are void. The vendor also disclaims liability for special, indirect, punitive, incidental, or consequential damages. It's worth noting that some jurisdictions may not allow exclusion or limitation of certain types of damages, so this warranty may not apply to you in its entirety.