

Continue



Raymond pallet jack error codes e250

Raymond pallet jack error code e250. Raymond pallet jack code e250. Raymond pallet jack error code e225. Raymond pallet jack e250. Raymond e250 code.

This website is best viewed in Internet Explorer 10 or above, so please update your browser for a correct viewing experience. For optimal use of this site, we recommend using Internet Explorer 10 or above as well. You can download our app by scanning the QR code below or check it out in the app stores. When your RaymondCorp lift truck malfunctions, refer to this handy error codes list to diagnose and troubleshoot any issues. The following codes are categorized into two groups: "C" for caution and "E" for error. C-codes do not store in memory and are only highlighted on the display until the issue is resolved. E-codes, on the other hand, indicate a malfunction or failure and store in long-term error memory. Common Raymond Electric Pallet Jack Error Codes Error Code C14: Arm Angle Reference Warning Error Code C19: Default Parameter Warning Error Code C20: Thumb Control Warning Error Code C23: Master Control ON/OFF Switch Warning Error Code E101: Power Amplifier Doesn't Correspond with the Type of Truck Error Code E104: Brake Output Error Error Code E106: Digital Output or Field Overcurrent Error Code E107: Contactor Off Error Code E108: Contactor Welded or Missing Error Code E110: Braking System Fault Powering on issues may arise if the amplifier detects stuck master control switches. With active Code C-28, lift and drive functions remain operational but with speed restrictions. Cycling the power usually resolves the issue once corrected. Try tapping the hydraulic motor starter switch or check wire connections to the switch. The switch itself may need replacement. Error Code C-20 signals issues with the "Thumb Control" not being in neutral at power ON or throttle position sensor failure. With this code active, drive functions are locked out while lifting remains operational. Start by inspecting the position sensor and connectors for damage. Check mechanical throttle controller parts and magnet arm alignment with ETAC sensors. Error Code E-101 suggests that the installed power amplifier is not compatible with ETAC software, halting all operations. Clear this code by updating to the correct amplifier software for the truck type. Error Code E-106 relates to "Digital Output" overcurrent faults in systems controlling contactors or traction motor fields. This code disables all motor functions until the issue is resolved. Error Code E-114 indicates a "Motor Speed Fault" due to stalled or excessive traction motor load at low speeds, and may block drive functions while allowing lift. Inspect brake assemblies and end bell contactors for sticking issues and consider reducing weight on board. Finally, Error Code E-150 highlights short or open circuits in open wiring or electrical noise in CAN wiring. This code disables all truck operations until communication is restored, which may require a power cycle. Check wire connections and power cycles as needed. Get connected: inspect bus connections for corrosion, damage, or loose contacts; ensure system ground is secure. If necessary, add shielding. To master the art of troubleshooting your Raymond electric pallet jack, consult the comprehensive error codes PDF guide. This valuable resource provides in-depth information on common error codes, their causes, performance implications, and step-by-step instructions to resolve them.