

I'm not a bot



Insinkerator pro ss installation manual

Insinkerator repair manual. Insinkerator model 46 installation instructions. Install insinkerator. Insinkerator installation manual.

Installing Your New InSinkErator Garbage Disposal: A Step-by-Step Guide If you're excited to start using your new InSinkErator garbage disposal, follow our easy-to-follow instructions to get started. With the right tools and a little patience, you'll be disposing of food waste in no time. Before You Begin: * Read through the entire safety and installation manual that came with your unit. * Make sure you have all the necessary parts and tools, including plumber's putty, wire nuts, and a dishwasher drain connector kit (if applicable). Step 1: Disconnect Pipes Use large channel-locks or a pipe wrench to loosen the nuts holding the pipes together. Remove any blockages in the horizontal drain pipe by cleaning it out. Step 2: Remove Old Disposal (If Applicable) Disconnect the down drainpipe and remove any old disposal parts. Make sure you have all parts removed before proceeding. Step 3: Prepare Drain Opening Unscrew the large nut holding the strainer in place, then remove the strainer body. Loosen the three screws on the mounting assembly and pry off the snap ring. Clean off old plumber's putty from around the drain opening. Step 4: Install New Sink Flange Place a 1/2" rope of plumber's putty around the drain opening in the sink. Drop the new sink flange into place, pressing it into position. Use your garbage disposal as a weight to hold the flange in place while mounting. Step 5: Mount Disposal Assembly Slide the fiber gasket, backup flange, and mounting flange over the sink flange from under the sink. Hold these parts in place. Next, slip on the mounting ring and snap ring. Tighten the three screws, alternating each one a few turns at a time until it's evenly seated against the bottom of the sink. Step 6: Prepare for Dishwasher (If Applicable) For hardwired units with cords, you'll need to tap out the dishwasher knockout plug using a screwdriver and hammer. Remove any loose plugs from inside the disposal. Replace electrical cover plate once completed. That's it! With these steps, you should be able to successfully install your new InSinkErator garbage disposal. A kit to power a garbage disposal, which can be installed by following the instructions found here. To install a disposal with a built-in cord, simply plug it into the outlet under your sink after completing the rest of the installation process. Secure the disposal by aligning its mounting tabs with the slide-up ramps on the mounting ring and tightening the lower ring until all tabs are locked in place. Insert the discharge tube into the coupler, then secure it with a clamp and position it in the groove on the tailpipe coupler. Ensure the tube is aligned with the drain trap and cut or replace it as needed. If connecting to a dishwasher, attach the drain hose using a hose clamp. Finally, lock the disposal to the sink assembly, insert the Quiet Collar into the sink opening, and test for leaks at all connections before turning on the power. To install your new InSinkErator garbage disposal easily, follow these steps after reading the safety and installation instructions provided. For a first-time installation, proceed as follows: From under the sink, place the fiber gasket, backup flange, and mounting ring over the sink flange, holding them in place while inserting the snap ring. Tighten the screws evenly until the assembly is securely seated against the sink's bottom. If your sink is thicker than 3/8", use shorter screws. Be cautious not to insert fingers into the discharge opening. Trim the discharge tube if necessary for a proper fit. Models with tailpipe gaskets/flanges require removing labels, sliding flanges over tubes, and securing with bolts. Alternatively, models with Anti-vibration Tailpipe Mounts involve inserting the mount into the disposer's outlet, securing it with bolts, then attaching the discharge tube with a spring clamp. Although curved tubes are preferred, straight ones can be used but must have a slight downward pitch to prevent water leakage. Hang the disposer by aligning its mounting tabs with the slide-up ramps on the mounting ring, turning counter-clockwise until the discharge tube aligns with plumbing. Secure the lower mounting ring using a wrenchette until all tabs latch over the ridges on the ramps. Remove the dishwasher inlet plug (if applicable) and reconnect plumbing after checking for leaks by filling the sink with water and observing the disposal in action. Fix the leaky sink by reconnecting power at the fuse or circuit breaker box. Your disposer should now be working properly. If you need further assistance, consider contacting a professional for personalized installation support, such as calling (262) 233-2231. For added help, reach out to our support team.