




- HOW TO:**
1. **Connect your Tuff Tank to a toilet block (etc.)**
 2. **Control potential malodour with an odour trap**
 3. **Empty tanks using a liquid waste haulier**

1. WC-Connector Kit

(SKU: WC-Connector-Kit-01)



Use 2 x 5" lids for
1. waste "in" and
2. odour control



A 4" tank adaptor plus a flexible WC pan connector make the link from toilet block to tank.

2. Odour Control Trap

(SKU: Tank-Breather-Kit-01)



Liquid entering the tank displaces air, which may smell. This odour trap uses an active carbon filter to dry and cleanse the air.

3. Emptying tanks



Use either of
2 x 12" lids for
emptying tanks

