

**CORRECTIONS ON ACCOUNT OF TEMPERATURE TO BE APPLIED TO THE INDICATIONS OF
A GLASS 20°C/20°C SACCHAROMETER TO GIVE THE GRAVITY OF WORTS (20°C/20°C)**

NOT TO BE USED WITH ANY OTHER SACCHAROMETER

BS15G

NOTE: When the apparent gravity falls between the gravities given in the table, the correction for the lower gravity is to be applied.

		TEMPERATURE IN DEGREES CELSIUS																																	
		2.0	2.5	3.0	3.5	4.0	4.5	5.0	5.5	6.0	6.5	7.0	7.5	8.0	8.5	9.0	9.5	10.0	10.5	11.0	11.5	12.0	12.5	13.0	13.5	14.0	14.5	15.0	15.5		16.0	16.5	17.0		
A P P A R E N T G R A V I T Y	1000	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	1000		
	1005	-1.9	-1.9	-1.9	-1.8	-1.8	-1.8	-1.8	-1.7	-1.7	-1.7	-1.7	-1.7	-1.6	-1.6	-1.6	-1.5	-1.5	-1.5	-1.4	-1.4	-1.3	-1.3	-1.2	-1.2	-1.1	-1.1	-1.0	-1.0	-0.9	-0.8	-0.7	-0.6	1005	
	1010	-2.0	-2.0	-2.0	-1.9	-1.9	-1.9	-1.9	-1.8	-1.8	-1.8	-1.7	-1.7	-1.7	-1.7	-1.6	-1.6	-1.5	-1.5	-1.5	-1.4	-1.4	-1.3	-1.3	-1.2	-1.2	-1.1	-1.1	-1.0	-1.0	-0.9	-0.8	-0.7	-0.6	1010
	1015	-2.1	-2.1	-2.1	-2.0	-2.0	-2.0	-1.9	-1.9	-1.9	-1.8	-1.8	-1.8	-1.7	-1.7	-1.6	-1.6	-1.6	-1.5	-1.5	-1.4	-1.4	-1.3	-1.3	-1.3	-1.2	-1.1	-1.1	-1.0	-1.0	-0.9	-0.7	-0.6	1015	
	1020	-2.2	-2.2	-2.2	-2.1	-2.1	-2.1	-2.0	-2.0	-2.0	-1.9	-1.9	-1.9	-1.8	-1.8	-1.8	-1.7	-1.7	-1.6	-1.6	-1.5	-1.5	-1.4	-1.3	-1.3	-1.3	-1.2	-1.2	-1.1	-1.0	-1.0	-0.9	-0.7	-0.6	1020
	1025	-2.3	-2.3	-2.3	-2.2	-2.2	-2.2	-2.1	-2.1	-2.0	-2.0	-2.0	-2.0	-1.9	-1.9	-1.8	-1.8	-1.7	-1.7	-1.6	-1.6	-1.5	-1.4	-1.4	-1.3	-1.3	-1.3	-1.2	-1.1	-1.1	-1.0	-0.9	-0.8	-0.6	1025
	1030	-2.4	-2.4	-2.4	-2.3	-2.3	-2.2	-2.2	-2.2	-2.1	-2.1	-2.0	-2.0	-2.0	-1.9	-1.9	-1.8	-1.8	-1.7	-1.7	-1.6	-1.5	-1.5	-1.4	-1.4	-1.3	-1.2	-1.2	-1.1	-1.0	-0.9	-0.8	-0.7	1030	
	1035	-2.5	-2.5	-2.5	-2.4	-2.4	-2.3	-2.3	-2.2	-2.2	-2.2	-2.1	-2.0	-2.0	-2.0	-1.9	-1.9	-1.8	-1.8	-1.7	-1.6	-1.6	-1.5	-1.5	-1.4	-1.3	-1.2	-1.2	-1.1	-1.0	-0.9	-0.8	-0.7	1035	
	1040	-2.6	-2.6	-2.6	-2.5	-2.5	-2.4	-2.4	-2.3	-2.3	-2.2	-2.2	-2.1	-2.1	-2.1	-2.0	-1.9	-1.9	-1.8	-1.8	-1.7	-1.6	-1.6	-1.5	-1.4	-1.3	-1.3	-1.2	-1.1	-1.0	-0.9	-0.8	-0.7	1040	
	1045	-2.7	-2.7	-2.7	-2.6	-2.6	-2.5	-2.5	-2.4	-2.4	-2.3	-2.2	-2.2	-2.2	-2.1	-2.1	-2.0	-1.9	-1.9	-1.8	-1.7	-1.7	-1.6	-1.5	-1.5	-1.4	-1.3	-1.2	-1.1	-1.1	-1.0	-0.9	-0.8	-0.7	1045
	1050	-2.9	-2.8	-2.8	-2.7	-2.7	-2.6	-2.6	-2.5	-2.4	-2.4	-2.3	-2.3	-2.2	-2.1	-2.1	-2.0	-1.9	-1.9	-1.8	-1.7	-1.6	-1.6	-1.5	-1.5	-1.4	-1.3	-1.2	-1.2	-1.1	-1.0	-0.8	-0.7	1050	
	1055	-3.0	-2.9	-2.9	-2.8	-2.7	-2.7	-2.6	-2.6	-2.5	-2.5	-2.4	-2.3	-2.3	-2.2	-2.1	-2.1	-2.0	-1.9	-1.8	-1.8	-1.7	-1.6	-1.6	-1.5	-1.4	-1.3	-1.3	-1.2	-1.1	-1.0	-0.8	-0.7	1055	
	1060	-3.1	-3.0	-3.0	-2.9	-2.8	-2.8	-2.7	-2.7	-2.6	-2.5	-2.5	-2.4	-2.4	-2.3	-2.3	-2.2	-2.1	-2.0	-2.0	-1.9	-1.8	-1.7	-1.6	-1.5	-1.5	-1.4	-1.3	-1.2	-1.1	-1.0	-0.9	-0.7	1060	
	1065	-3.2	-3.1	-3.1	-3.0	-2.9	-2.9	-2.8	-2.7	-2.7	-2.6	-2.5	-2.5	-2.4	-2.4	-2.3	-2.2	-2.2	-2.1	-2.0	-1.9	-1.8	-1.8	-1.7	-1.6	-1.5	-1.4	-1.3	-1.2	-1.1	-1.0	-0.9	-0.7	1065	
	1070	-3.3	-3.2	-3.2	-3.1	-3.0	-3.0	-2.9	-2.8	-2.8	-2.7	-2.6	-2.5	-2.5	-2.4	-2.3	-2.2	-2.1	-2.1	-2.0	-1.9	-1.8	-1.7	-1.6	-1.5	-1.4	-1.3	-1.2	-1.1	-1.0	-0.9	-0.8	1070		
	1075	-3.4	-3.3	-3.3	-3.2	-3.1	-3.1	-3.0	-2.9	-2.8	-2.8	-2.7	-2.6	-2.5	-2.4	-2.4	-2.3	-2.2	-2.1	-2.0	-1.9	-1.8	-1.7	-1.6	-1.5	-1.4	-1.3	-1.2	-1.1	-1.0	-0.9	-0.8	1075		
	1080	-3.5	-3.4	-3.4	-3.3	-3.2	-3.1	-3.1	-3.0	-2.9	-2.8	-2.8	-2.7	-2.6	-2.5	-2.4	-2.3	-2.2	-2.2	-2.1	-2.0	-1.9	-1.8	-1.7	-1.6	-1.5	-1.4	-1.3	-1.2	-1.0	-0.9	-0.8	1080		
	1085	-3.6	-3.5	-3.5	-3.4	-3.3	-3.2	-3.2	-3.1	-3.0	-2.9	-2.8	-2.7	-2.7	-2.6	-2.5	-2.4	-2.3	-2.2	-2.1	-2.0	-1.9	-1.8	-1.7	-1.6	-1.5	-1.4	-1.3	-1.2	-1.0	-0.9	-0.8	1085		
	1090	-3.7	-3.6	-3.6	-3.5	-3.4	-3.3	-3.2	-3.2	-3.1	-3.0	-2.9	-2.8	-2.7	-2.6	-2.5	-2.4	-2.3	-2.3	-2.2	-2.1	-1.9	-1.8	-1.7	-1.6	-1.5	-1.4	-1.3	-1.2	-1.1	-0.9	-0.8	1090		
	1095	-3.8	-3.7	-3.7	-3.6	-3.5	-3.4	-3.3	-3.2	-3.2	-3.1	-3.0	-2.9	-2.8	-2.7	-2.6	-2.5	-2.4	-2.3	-2.2	-2.1	-2.0	-1.9	-1.8	-1.7	-1.6	-1.4	-1.3	-1.2	-1.1	-0.9	-0.8	1095		
1100	-3.9	-3.8	-3.8	-3.7	-3.6	-3.5	-3.4	-3.3	-3.2	-3.1	-3.0	-3.0	-2.9	-2.8	-2.7	-2.6	-2.5	-2.4	-2.2	-2.1	-2.0	-1.9	-1.8	-1.7	-1.6	-1.5	-1.3	-1.2	-1.1	-1.0	-0.8	1100			
1105	-4.0	-3.9	-3.9	-3.8	-3.7	-3.6	-3.5	-3.4	-3.3	-3.2	-3.1	-3.0	-2.9	-2.8	-2.7	-2.6	-2.5	-2.4	-2.3	-2.2	-2.1	-2.0	-1.8	-1.7	-1.6	-1.5	-1.4	-1.2	-1.1	-1.0	-0.8	1105			
1110	-4.1	-4.0	-4.0	-3.9	-3.8	-3.7	-3.6	-3.5	-3.4	-3.3	-3.2	-3.1	-3.0	-2.9	-2.8	-2.7	-2.6	-2.4	-2.3	-2.2	-2.1	-2.0	-1.9	-1.7	-1.6	-1.5	-1.4	-1.3	-1.1	-1.0	-0.9	1110			
1115	-4.2	-4.2	-4.1	-4.0	-3.9	-3.8	-3.7	-3.6	-3.5	-3.4	-3.3	-3.2	-3.1	-2.9	-2.8	-2.7	-2.6	-2.5	-2.4	-2.3	-2.1	-2.0	-1.9	-1.8	-1.7	-1.5	-1.4	-1.3	-1.1	-1.0	-0.9	1115			
1120	-4.3	-4.3	-4.2	-4.1	-4.0	-3.9	-3.8	-3.7	-3.6	-3.4	-3.3	-3.2	-3.1	-3.0	-2.9	-2.8	-2.7	-2.5	-2.4	-2.3	-2.2	-2.1	-1.9	-1.8	-1.7	-1.5	-1.4	-1.3	-1.1	-1.0	-0.9	1120			
1125	-4.5	-4.4	-4.3	-4.2	-4.1	-4.0	-3.8	-3.7	-3.6	-3.5	-3.4	-3.3	-3.2	-3.1	-3.0	-2.8	-2.7	-2.6	-2.5	-2.3	-2.2	-2.1	-2.0	-1.8	-1.7	-1.6	-1.4	-1.3	-1.2	-1.0	-0.9	1125			
1130	-4.6	-4.5	-4.4	-4.3	-4.2	-4.0	-3.9	-3.8	-3.7	-3.6	-3.5	-3.4	-3.3	-3.1	-3.0	-2.9	-2.8	-2.6	-2.5	-2.4	-2.3	-2.1	-2.0	-1.9	-1.7	-1.6	-1.5	-1.3	-1.2	-1.0	-0.9	1130			
1135	-4.7	-4.6	-4.5	-4.4	-4.2	-4.1	-4.0	-3.9	-3.8	-3.7	-3.6	-3.4	-3.3	-3.2	-3.1	-3.0	-2.8	-2.7	-2.6	-2.4	-2.3	-2.2	-2.0	-1.9	-1.8	-1.6	-1.5	-1.3	-1.2	-1.1	-0.9	1135			
1140	-4.8	-4.7	-4.6	-4.4	-4.3	-4.2	-4.1	-4.0	-3.9	-3.8	-3.6	-3.5	-3.4	-3.3	-3.1	-3.0	-2.9	-2.7	-2.6	-2.5	-2.3	-2.2	-2.1	-1.9	-1.8	-1.6	-1.5	-1.3	-1.2	-1.1	-0.9	1140			
1145	-4.9	-4.8	-4.7	-4.5	-4.4	-4.3	-4.2	-4.1	-4.0	-3.8	-3.7	-3.6	-3.5	-3.3	-3.2	-3.1	-2.9	-2.8	-2.7	-2.5	-2.4	-2.2	-2.1	-2.0	-1.8	-1.7	-1.5	-1.4	-1.2	-1.1	-0.9	1145			
1150	-5.0	-4.9	-4.8	-4.6	-4.5	-4.4	-4.3	-4.2	-4.0	-3.9	-3.8	-3.7	-3.5	-3.4	-3.3	-3.1	-3.0	-2.8	-2.7	-2.6	-2.4	-2.3	-2.1	-2.0	-1.8	-1.7	-1.5	-1.4	-1.2	-1.1	-1.0	1150			
		2.0	2.5	3.0	3.5	4.0	4.5	5.0	5.5	6.0	6.5	7.0	7.5	8.0	8.5	9.0	9.5	10.0	10.5	11.0	11.5	12.0	12.5	13.0	13.5	14.0	14.5	15.0	15.5	16.0	16.5	17.0			

Minus sign indicates that correction is to be made by subtraction, plus sign indicates that correction is to be made by addition.

**CORRECTIONS ON ACCOUNT OF TEMPERATURE TO BE APPLIED TO THE INDICATIONS OF
A GLASS 20°C/20°C SACCHAROMETER TO GIVE THE GRAVITY OF WORTS (20°C/20°C)**

NOT TO BE USED WITH ANY OTHER SACCHAROMETER

BS15G

NOTE: When the apparent gravity falls between the gravities given in the table, the correction for the lower gravity is to be applied.

		TEMPERATURE IN DEGREES CELSIUS																																
		17.0	17.5	18.0	18.5	19.0	19.5	20.0	20.5	21.0	21.5	22.0	22.5	23.0	23.5	24.0	24.5	25.0	25.5	26.0	26.5	27.0	27.5	28.0	28.5	29.0	29.5	30.0	30.5	31.0	31.5	32.0		
A P P A R E N T G R A D I E N T S	1000	---	---	---	---	---	---	+0.0	+0.2	+0.3	+0.5	+0.6	+0.7	+0.8	+0.9	+1.0	+1.2	+1.3	+1.4	+1.5	+1.6	+1.7	+1.8	+2.0	+2.1	+2.2	+2.3	+2.4	+2.5	+2.6	+2.7	+2.8	+2.9	1000
	1005	-0.6	-0.5	-0.4	-0.2	-0.1	+0.0	+0.0	+0.2	+0.3	+0.5	+0.6	+0.7	+0.8	+0.9	+1.0	+1.2	+1.3	+1.4	+1.5	+1.6	+1.8	+1.9	+2.0	+2.1	+2.2	+2.3	+2.5	+2.6	+2.7	+2.8	+2.9	1005	
	1010	-0.6	-0.5	-0.4	-0.3	-0.1	+0.0	+0.0	+0.2	+0.3	+0.5	+0.6	+0.7	+0.8	+0.9	+1.1	+1.2	+1.3	+1.4	+1.5	+1.7	+1.8	+1.9	+2.0	+2.1	+2.3	+2.4	+2.5	+2.6	+2.7	+2.9	+3.0	1010	
	1015	-0.6	-0.5	-0.4	-0.3	-0.1	+0.0	+0.0	+0.2	+0.3	+0.5	+0.6	+0.7	+0.8	+0.9	+1.1	+1.2	+1.3	+1.4	+1.6	+1.7	+1.8	+1.9	+2.0	+2.2	+2.3	+2.4	+2.5	+2.7	+2.8	+2.9	+3.0	1015	
	1020	-0.6	-0.5	-0.4	-0.3	-0.1	+0.0	+0.0	+0.2	+0.3	+0.5	+0.6	+0.7	+0.8	+0.9	+1.1	+1.2	+1.3	+1.5	+1.6	+1.7	+1.8	+1.9	+2.1	+2.2	+2.3	+2.5	+2.6	+2.7	+2.8	+3.0	+3.1	1020	
	1025	-0.6	-0.5	-0.4	-0.3	-0.2	+0.0	+0.0	+0.2	+0.3	+0.5	+0.6	+0.7	+0.8	+1.0	+1.1	+1.2	+1.3	+1.5	+1.6	+1.7	+1.8	+2.0	+2.1	+2.2	+2.4	+2.5	+2.6	+2.7	+2.9	+3.0	+3.1	1025	
	1030	-0.7	-0.5	-0.4	-0.3	-0.2	+0.0	+0.0	+0.2	+0.3	+0.5	+0.6	+0.7	+0.8	+1.0	+1.1	+1.2	+1.3	+1.5	+1.6	+1.7	+1.9	+2.0	+2.1	+2.3	+2.4	+2.5	+2.7	+2.8	+2.9	+3.1	+3.2	1030	
	1035	-0.7	-0.5	-0.4	-0.3	-0.2	+0.0	+0.0	+0.2	+0.3	+0.5	+0.6	+0.7	+0.8	+1.0	+1.1	+1.2	+1.4	+1.5	+1.6	+1.8	+1.9	+2.0	+2.2	+2.3	+2.4	+2.6	+2.7	+2.8	+3.0	+3.1	+3.2	1035	
	1040	-0.7	-0.6	-0.4	-0.3	-0.2	-0.1	+0.0	+0.2	+0.3	+0.5	+0.6	+0.7	+0.8	+1.0	+1.1	+1.2	+1.4	+1.5	+1.6	+1.8	+1.9	+2.0	+2.2	+2.3	+2.5	+2.6	+2.7	+2.9	+3.0	+3.2	+3.3	1040	
	1045	-0.7	-0.6	-0.4	-0.3	-0.2	-0.1	+0.0	+0.2	+0.3	+0.5	+0.6	+0.7	+0.8	+1.0	+1.1	+1.2	+1.4	+1.5	+1.7	+1.8	+1.9	+2.1	+2.2	+2.4	+2.5	+2.6	+2.8	+2.9	+3.1	+3.2	+3.4	1045	
	1050	-0.7	-0.6	-0.5	-0.3	-0.2	-0.1	+0.0	+0.2	+0.3	+0.5	+0.6	+0.7	+0.9	+1.0	+1.1	+1.3	+1.4	+1.5	+1.7	+1.8	+2.0	+2.1	+2.2	+2.4	+2.5	+2.7	+2.8	+3.0	+3.1	+3.3	+3.4	1050	
	1055	-0.7	-0.6	-0.5	-0.3	-0.2	-0.1	+0.0	+0.2	+0.3	+0.5	+0.6	+0.7	+0.9	+1.0	+1.1	+1.3	+1.4	+1.6	+1.7	+1.9	+2.0	+2.1	+2.3	+2.4	+2.6	+2.7	+2.9	+3.0	+3.2	+3.3	+3.5	1055	
	1060	-0.7	-0.6	-0.5	-0.3	-0.2	-0.1	+0.0	+0.2	+0.3	+0.5	+0.6	+0.7	+0.9	+1.0	+1.1	+1.3	+1.4	+1.6	+1.7	+1.9	+2.0	+2.1	+2.3	+2.4	+2.6	+2.7	+2.9	+3.0	+3.2	+3.4	+3.5	1060	
	1065	-0.7	-0.6	-0.5	-0.4	-0.2	-0.1	+0.0	+0.2	+0.3	+0.5	+0.6	+0.7	+0.9	+1.0	+1.1	+1.3	+1.4	+1.6	+1.7	+1.9	+2.0	+2.2	+2.3	+2.5	+2.6	+2.8	+2.9	+3.1	+3.2	+3.4	+3.6	1065	
	1070	-0.8	-0.6	-0.5	-0.4	-0.2	-0.1	+0.0	+0.2	+0.3	+0.4	+0.6	+0.7	+0.9	+1.0	+1.2	+1.3	+1.4	+1.6	+1.7	+1.9	+2.0	+2.2	+2.3	+2.5	+2.7	+2.8	+3.0	+3.1	+3.3	+3.5	+3.6	1070	
T G R A V I T Y	1075	-0.8	-0.6	-0.5	-0.4	-0.2	-0.1	+0.0	+0.2	+0.3	+0.4	+0.6	+0.7	+0.9	+1.0	+1.2	+1.3	+1.5	+1.6	+1.8	+1.9	+2.1	+2.2	+2.4	+2.5	+2.7	+2.9	+3.0	+3.2	+3.3	+3.5	+3.7	1075	
	1080	-0.8	-0.6	-0.5	-0.4	-0.2	-0.1	+0.0	+0.2	+0.3	+0.4	+0.6	+0.7	+0.9	+1.0	+1.2	+1.3	+1.5	+1.6	+1.8	+1.9	+2.1	+2.2	+2.4	+2.6	+2.7	+2.9	+3.0	+3.2	+3.4	+3.5	+3.7	1080	
	1085	-0.8	-0.7	-0.5	-0.4	-0.3	-0.1	+0.0	+0.2	+0.3	+0.4	+0.6	+0.7	+0.9	+1.0	+1.2	+1.3	+1.5	+1.6	+1.8	+2.0	+2.1	+2.3	+2.4	+2.6	+2.8	+2.9	+3.1	+3.3	+3.4	+3.6	+3.8	1085	
	1090	-0.8	-0.7	-0.5	-0.4	-0.3	-0.1	+0.0	+0.2	+0.3	+0.4	+0.6	+0.7	+0.9	+1.0	+1.2	+1.3	+1.5	+1.7	+1.8	+2.0	+2.1	+2.3	+2.5	+2.6	+2.8	+3.0	+3.1	+3.3	+3.5	+3.6	+3.8	1090	
	1095	-0.8	-0.7	-0.5	-0.4	-0.3	-0.1	+0.0	+0.2	+0.3	+0.4	+0.6	+0.7	+0.9	+1.0	+1.2	+1.4	+1.5	+1.7	+1.8	+2.0	+2.1	+2.3	+2.5	+2.7	+2.8	+3.0	+3.2	+3.3	+3.5	+3.7	+3.9	1095	
	1100	-0.8	-0.7	-0.6	-0.4	-0.3	-0.1	+0.0	+0.2	+0.3	+0.4	+0.6	+0.7	+0.9	+1.1	+1.2	+1.4	+1.5	+1.7	+1.8	+2.0	+2.2	+2.3	+2.5	+2.7	+2.9	+3.0	+3.2	+3.4	+3.6	+3.7	+3.9	1100	
	1105	-0.8	-0.7	-0.6	-0.4	-0.3	-0.1	+0.0	+0.1	+0.3	+0.4	+0.6	+0.7	+0.9	+1.1	+1.2	+1.4	+1.5	+1.7	+1.9	+2.0	+2.2	+2.4	+2.5	+2.7	+2.9	+3.1	+3.2	+3.4	+3.6	+3.8	+4.0	1105	
	1110	-0.9	-0.7	-0.6	-0.4	-0.3	-0.1	+0.0	+0.1	+0.3	+0.4	+0.6	+0.8	+0.9	+1.1	+1.2	+1.4	+1.6	+1.7	+1.9	+2.1	+2.2	+2.4	+2.6	+2.7	+2.9	+3.1	+3.3	+3.5	+3.7	+3.8	+4.0	1110	
	1115	-0.9	-0.7	-0.6	-0.4	-0.3	-0.2	+0.0	+0.1	+0.3	+0.4	+0.6	+0.8	+0.9	+1.1	+1.2	+1.4	+1.6	+1.7	+1.9	+2.1	+2.2	+2.4	+2.6	+2.8	+3.0	+3.1	+3.3	+3.5	+3.7	+3.9	+4.1	1115	
	1120	-0.9	-0.7	-0.6	-0.5	-0.3	-0.2	+0.0	+0.1	+0.3	+0.4	+0.6	+0.8	+0.9	+1.1	+1.2	+1.4	+1.6	+1.7	+1.9	+2.1	+2.3	+2.4	+2.6	+2.8	+3.0	+3.2	+3.4	+3.6	+3.7	+3.9	+4.1	1120	
	1125	-0.9	-0.8	-0.6	-0.5	-0.3	-0.2	+0.0	+0.1	+0.3	+0.4	+0.6	+0.8	+0.9	+1.1	+1.3	+1.4	+1.6	+1.8	+1.9	+2.1	+2.3	+2.5	+2.7	+2.8	+3.0	+3.2	+3.4	+3.6	+3.8	+4.0	+4.2	1125	
	1130	-0.9	-0.8	-0.6	-0.5	-0.3	-0.2	+0.0	+0.1	+0.3	+0.4	+0.6	+0.8	+0.9	+1.1	+1.3	+1.4	+1.6	+1.8	+2.0	+2.1	+2.3	+2.5	+2.7	+2.9	+3.1	+3.2	+3.4	+3.6	+3.8	+4.0	+4.2	1130	
1135	-0.9	-0.8	-0.6	-0.5	-0.3	-0.2	+0.0	+0.1	+0.3	+0.4	+0.6	+0.8	+0.9	+1.1	+1.3	+1.4	+1.6	+1.8	+2.0	+2.2	+2.3	+2.5	+2.7	+2.9	+3.1	+3.3	+3.5	+3.7	+3.9	+4.1	+4.3	1135		
1140	-0.9	-0.8	-0.6	-0.5	-0.3	-0.2	+0.0	+0.1	+0.3	+0.4	+0.6	+0.8	+0.9	+1.1	+1.3	+1.5	+1.6	+1.8	+2.0	+2.2	+2.4	+2.5	+2.7	+2.9	+3.1	+3.3	+3.5	+3.7	+3.9	+4.1	+4.3	1140		
1145	-0.9	-0.8	-0.7	-0.5	-0.4	-0.2	+0.0	+0.1	+0.3	+0.4	+0.6	+0.8	+0.9	+1.1	+1.3	+1.5	+1.6	+1.8	+2.0	+2.2	+2.4	+2.6	+2.8	+3.0	+3.2	+3.4	+3.6	+3.8	+4.0	+4.2	+4.4	1145		
1150	-1.0	-0.8	-0.7	-0.5	-0.4	-0.2	+0.0	+0.1	+0.3	+0.4	+0.6	+0.8	+0.9	+1.1	+1.3	+1.5	+1.7	+1.8	+2.0	+2.2	+2.4	+2.6	+2.8	+3.0	+3.2	+3.4	+3.6	+3.8	+4.0	+4.2	+4.4	1150		
		17.0	17.5	18.0	18.5	19.0	19.5	20.0	20.5	21.0	21.5	22.0	22.5	23.0	23.5	24.0	24.5	25.0	25.5	26.0	26.5	27.0	27.5	28.0	28.5	29.0	29.5	30.0	30.5	31.0	31.5	32.0		

Minus sign indicates that correction is to be made by subtraction, plus sign indicates that correction is to be made by addition.