



CORNELIUS INC ■ One Cornelius Place ■ Anoka, MN 55303-6234

Telephone (800) 238-3600

Facsimile (800) 535-4231

INSTALLATION INSTRUCTIONS

QCD CONNECTOR O-RING FIELD REPLACEMENT KIT PART NO. 810160000

Table 1. Loose-Shipped Parts			
Item No.	Part No.	Name	Qty.
1	560002019	O-Ring .208 ID x .070 CS QCD-II and QCD 2	1
2	560002020	O-Ring .551 ID x .070 CS QCD-II and QCD 2	1
3	560002022	O-Ring, .674 ID x .103 CS QCD-II	1
4	560002021	O-Ring, .424 ID x .103 CS QCD 2	1
5	569000120	Instructions	1

Note: The connector could be either QCD-II or QCD-2 type.

INSTALLATION INSTRUCTIONS:

1. Disconnect the connector from the BNB box.
2. Disassemble the QCD II connector cap assembly, by unscrewing (counterclockwise) using a flat blade screwdriver. The QCD 2 connector requires 1/8 turn (counterclockwise) to disassemble.
3. Remove the BIB sealing o-ring from the connector, and replace it with a new o-ring (item 2).
4. Remove o-ring from the probe body and replace it with a new matching o-ring (item 1).
5. Remove o-ring from cap assembly, and replace it with a new matching o-ring (item 3 or item 4) depending on connector type. Item 3 will fit QCD-II connector and Item 4 will fit QCD-2 connector.
6. Reassemble the connector.

