

KIT #2026

INSTALLATION INSTRUCTIONS

Hoshizaki Model KM451 Icemaker/Remcor Model TJ150 Dispenser

1. Seal icemaker to dispenser top cover as follows:
  - a. Locate outline of icemaker on dispenser cover as shown in attached sketch.
  - b. Run a bead of RTV around the inside of the icemaker outline on the cover.
  - c. Position the icemaker on the dispenser cover.
  - d. Wipe away any excess RTV immediately.
2. Using the mounting brackets as templates, locate and drill holes in the icemaker cabinet for the #10 sheet-metal screws provided in the kit. Install brackets.
3. Install insulation strip on cover bracket as shown.
4. Using the cover bracket as a template, locate and drill holes in the dispenser top cover for #10 sheet-metal screws. In locating cover bracket, position the bracket so that there is compression of the insulation against the icemaker cabinet to form a seal.
5. Follow the icemaker manufacturer's instructions to complete the installation. Check that the ice level control bracket does not interfere with the agitator in the dispenser ice storage hopper. "Raise" the icemaker control bracket if required.

