

THE ULTIMATE

THERMOFORMING TROUBLESHOOTING GUIDE

by THERMOFORA

XV
CHAPTERS

300+
DEFECTS DESCRIBED

Contents:

Contents:	2
I. Thermal Imbalance Defects	4
1. Overheating.....	4
2. Underheating.....	7
3. Uneven Heating.....	9
II. Moisture & Material Condition Defects	11
III. Vacuum & Airflow Defects	12
Vacuum System Mechanical Failures.....	14
IV. Geometric & Draw Ratio Defects	16
Wrinkle Formation.....	18
V. Pre-Stretch & Plug Assist Defects	20
VI. Cooling & Post-Form Defects	22
VII. Release & Demold Defects	24
VIII. Surface Quality Defects	26
IX. Clamping & Handling Defects	28
X. Trimming & Fabrication Defects	29
XI. Material-Specific Defects	32
ABS.....	32
PC (Polycarbonate).....	32
PMMA (Acrylic).....	33
PETG.....	33
PP (Polypropylene).....	34
XII. Machine & Control System Defects	34
Electrical and Power System.....	34
Heating System.....	37
Temperature Measurement & Sensors.....	39
Temperature Control (PID & Algorithms).....	40
PLC, HMI & Software.....	43
Electromagnetic & Signal Integrity.....	46
Pneumatic & Vacuum Systems.....	47
Cooling System.....	50
Mechanical & Structural Components.....	52
Drives & Motion Control.....	53
Heating System.....	56
Temperature Measurement & Sensors.....	58
Temperature Control (PID & Algorithms).....	60

PLC, HMI & Software.....	62
Electromagnetic & Signal Integrity.....	65
Pneumatic & Vacuum Systems.....	67
Cooling System.....	70
Mechanical & Structural Components.....	72
Drives & Motion Control.....	73
XIII. Long-Term Performance Defects.....	74
XIV. Process Stability Failures.....	75
XV. Multi-Cavity Thermoforming Defects.....	77

I. Thermal Imbalance Defects

Temperature control is the single most critical variable in thermoforming.

The defects in this section stem from three conditions: too much heat, too little heat, or heat unevenly distributed across the sheet. Each condition produces a distinct and recognizable pattern of failures.

1. Overheating

1. Blisters and Internal Bubbles

- **Cause:** Moisture trapped in the sheet vaporizes under heat, forming internal pockets. Overheating drives vapor pressure beyond the polymer's melt strength. Severe cases cause the surface to rupture - known as a steam burst. Hygroscopic materials (PC, ABS, Acrylic) are most at risk.
- **Solution:** Pre-dry hygroscopic sheets before forming (PC requires approx. 1 hr/mm at 90°C). Reduce the heat cycle time and monitor bottom sheet temperature with an IR sensor. Use staged pre-heating at 60°C to allow moisture to escape gradually before reaching forming temperature.

2. Microbubbles

- **Cause:** Polymer breakdown and gasification during the heating cycle - distinct from moisture blisters. Indicates the material is approaching its thermal degradation limit.
- **Solution:** Reduce oven temperature or dwell time. Avoid repeated re-extrusion of regrind material.

3. Surface Boiling Effect

- **Cause:** Extreme overheating causes the material surface to physically boil, producing a pitted or severely textured appearance.
- **Solution:** Decrease oven temperature and increase the distance between heating elements and the sheet.

4. Surface Gloss Change

- **Cause:** Overheating makes the material too fluid, causing it to copy mold imperfections prematurely or react to air currents, resulting in gloss loss or undulation.
- **Solution:** Reduce heating time and form at the correct tempering temperature rather than the upper operational limit.

5. Orange Peel Texture

- **Cause:** Prolonged heat soak at elevated temperature causes surface irregularities, particularly in thinner drawn areas.
- **Solution:** Eliminate heat soak for sensitive materials. Use screening (aluminum mesh) to reduce radiant energy in areas prone to thinning.

6. Sheet Sag and Pre-form Collapse

- **Cause:** When the polymer reaches its viscous state, gravity overcomes melt strength and the sheet sags uncontrollably. In large-format sheets or overly heated material, the pre-stretch bubble becomes unstable.
- **Solution:** Reduce heating cycle time. Install a photo-electric sag eye to trigger automatic air injection for sheet leveling. Use cooling screens in the center of the sheet for large formats.

7. Corner Tearing from Over-softened Sheet

- **Cause:** Excessive heat reduces tensile strength, causing the sheet to rupture when stretched over sharp radii or during deep draws.
- **Solution:** Decrease heat cycle time. Increase corner radii in the mold design.

8. Plug Mark Imprint

- **Cause:** When the sheet surface is too fluid, contact with a plug assist leaves a visible impression immediately upon touch.
- **Solution:** Wrap the plug in felt or flannel. Reduce heating time to maintain some surface resistance.

9. Nipples from Vent Holes

- **Cause:** Overheated, fluid material is drawn into vacuum vent holes by atmospheric pressure, forming small protrusions. Oversized vent holes make this worse.

- **Solution:** Reduce the heating cycle. Keep vent hole diameters between 1/32" and 1/8" (0.8–3.0 mm). Plug and re-drill any oversized holes.

10. Edge Thinning Collapse

- **Cause:** Excessive heat near the clamping frame – often from high perimeter zone settings – causes the sheet edges to pull away and thin severely.
- **Solution:** Use lower zone temperatures or aluminum screening at the perimeter.

11. Material Burning

- **Cause:** Unchecked heat absorption leads to polymer degradation: bubbling, charring, or scorching of the surface.
- **Solution:** Check for faulty heater zones or hot spots. Reduce overall temperature settings.

12. Acrylic Masking Damage

- **Cause:** Surface temperatures exceeding 420°F (215°C) cause protective masking to bake onto the sheet. It then breaks off in strips rather than peeling cleanly – this applies equally during forming and when stored at elevated temperatures.
- **Solution:** Use thermolabels to verify surface temperature stays below 420°F. Reduce top heater wattage or increase the heater-to-sheet distance.

13. Polymer Degradation Odor

- **Cause:** Overheating triggers molecular scission, releasing free monomers as a strong plastic-like smell – particularly in styrenics. Indicates irreversible reduction in molecular weight.
- **Solution:** Improve ventilation in the forming area. Optimize the heat cycle to prevent degradation temperatures from being reached.

14. Surface Discoloration

- **Cause:** Thermal instability causes yellowing or color loss in HIPS, ABS, and PVC at excessive temperatures.
- **Solution:** Reduce heating time and verify the material's thermal stability range with the supplier.

Intellectual Property Notice

© 2026 THERMOFORA LLC. All rights reserved.

This publication, including all text, structure, technical content, graphics, and intellectual concepts, is the exclusive intellectual property of THERMOFORA LLC.

No part of this document may be reproduced, distributed, transmitted, stored in a retrieval system, translated, resold, or used for commercial purposes in any form or by any means — electronic, mechanical, photocopying, recording, or otherwise — without prior written permission from THERMOFORA LLC.

Unauthorized reproduction or resale of this material is strictly prohibited and may result in legal action.

This guide is licensed for personal or internal company use only.

<https://vacuumforming3d.com/>

email: thermofora@gmail.com

This is a preview version of the guide. The full guide is available for purchase on our website.