



We Color You Safe!

Step



Guest Room Hygiene: Sequence & Process

PREPARATION



Note: The detailed Guest Room processing described here is a **TEMPLATE WHICH CAN BE EDITED** for a **STANDARDIZED** process. UMF will revise, retitle and edit as required to meet each hotel brands specific requirements.

CART: Prepare all items to be used or taken into the room

Put on gloves

Put on face mask (if required)



Avoid the **5**
Deadly Sins

- o Hair in the bed
- o Trash in the basket
- o Mildew in the tile grout
- o Hair on the bathroom floor
- o **Mattress stains**



Cleanliness Inspires Loyalty™

Training Video Available

A

Away with



Open Door and place DOOR-STOP

VISUAL INSPECTION: Walk into room with garbage bag & bed linen. Place linen on sofa/chair. Observe overall condition of room and note any issues.

Check all drawers for debris.

Check closet for all accessories.

Turn on ALL lights and open ALL curtains.

- *Make note of any light bulbs not working, condition of lamp shade & lamp.*
- *Make note of any issue with curtain/blind function*

Collect all garbage in the room. Look under the bed, under chairs, under desk, collecting and bagging any debris.

Empty waste baskets & recycling containers. Clean out containers as required - wipe down rims and exterior with disinfectant by spraying disinfectant on a **YELLOW PerfectCLEAN WIPER** (do not spray disinfectant on container).

Collect the following items (if dirty): Ice bucket, dishes, coffeepot, coffee basket, etc. Place all items in sink or dishwasher.

Take all dirty glassware to your cart. Trays & dishes placed in hall.

In the BATHROOM – First, Shake shower curtain vigorously. Pick-up towels and put in laundry bag. Remove any litter. *Avoid contact with any Guest personal items*. *For stay-over guests, carefully move items to one side of the vanity*. *For GLASS swing door or GLASS sliding door see Miscellaneous below.*

Check condition of shower curtain, curtain hooks and use a DRY PerfectCLEAN **12" ORANGE FLAT MOP** on bathroom floor to remove any hair and dust. If mop head is covered in hair, remove mop at the door and place in soiled-laundry bag.

NEXT: PREPARE BEDROOM.

Training Video Available 

Copyright UMF Corporation 2020 © All Rights Reserved

B

Bed & Bedding



STRIP BED: First check both sides of the duvet cover – if stained remove (*according to HOST policy*).

Check the sheets and pillowcases for stains or spills. Before removing sheets check carefully to make sure there are no wet spots.

To remove sheets - carefully fold corners to middle, ball up and remove avoiding contact with your clothing. Bag all soiled linens.

If you suspect urine or other bodily fluids carefully go to cart and get a plastic bag. Carefully fold sheets and mattress protector (*if used*) so as to NOT make contact with fluids and place in plastic bag and seal the bag. Call HOST for pickup.

Before making the bed, check the mattress pad and/or mattress for any stains and/or odors. Evidence of any type of body fluid or unusual odor should be immediately reported to your manager. Reposition the mattress as necessary.

Make the Bed(s).

Training Video Available 

C

Cleaning Chemicals



Clean dirty coffeepot, basket, and ice bucket using dishwashing liquid and a PerfectCLEAN **GRAY SPONGE**. Thoroughly rinse and dry with a **16" GRAY PerfectCLEAN WIPER** and return to proper location. Clean and check hair dryer.

RETURN TO BATHROOM. Start by misting bathroom surfaces using ("*insert type*") disinfectant. Start high (shower head & walls) to low (base of toilet). Mist faucets (sink & shower), sink & tub drains, soap dish, towel holders, etc.

DO NOT FLUSH THE TOILET AT THIS TIME (*toilet plume creates a bio-aerosol which can make you and the Guest sick*) - **must allow disinfectant to achieve dwell time** .

Spray disinfectant on toilet covering: tank, tank base, flusher, seat & seat cover, toilet base, inside of toilet.

Mist doorknobs.

NOTE: *The room attendant should be familiar with the dwell time and any precautions for the disinfectant used.*

DO NOT WIPE DOWN THE BATHROOM AT THIS TIME - must achieve disinfectant dwell time

Check Level of Hand Sanitizer and Disinfectant Wipes - refill/replace as required (*if applicable*).

ONEper ROOM METHODOLOGY: All cleaning products used go into the soiled laundry bag and NEVER into another Guest Room.

Training Video Available 

D

Dusting & Disinfecting

Starting at the door, walk the room(s) in a circle using a DRY PerfectCLEAN **BLUE FRINGED FLEXIBLE DUSTER** to dust all high surfaces: Picture Frames; Head Board; Fan Blades; Door & Window Frames; Valances; Lamp Shades; Behind Wall mounted TV and any other difficult to reach surfaces.

Lightly mist the PerfectClean **BLUE FRINGED FLEXIBLE DUSTER** to clean air vents and returns.

F

Finish the



- Put on **BLUE GLOVES**.
- Clean the closet. Check over the iron & ironing board making note of any damage.
- Then wipe down luggage rack, hangers, rods and safe.
- Perform a visual inventory of bedroom & closet amenities.
- Starting at the far end of the room, vacuum it, turning off all lights as you go. Vacuum your way out of the room.
- Final Step:** Using a **YELLOW WIPER** and disinfectant wipe down all frequently touched surfaces including: Light Switch; TV Remote; Phone; All Drawer Pulls and Door Handles; Thermostat; PTAC Control Panel & Cover; Alarm Clock; Over-bed Reading Lights; when complete **YELLOW WIPER** goes in soiled laundry bag.
- Take one last look around to make sure lampshades are straight, bed covers hang properly, etc.
- Take a moment to enjoy the pride in a job well done!**
- Securely close the entrance door and wipe down entire handle area/key card device.
- Check cart in preparation for next Guest Room.
- Remove gloves and discard. **Sanitize hands.**
- "Hygienically Cleaned for Your Peace of Mind"** Room Seal - if used apply as per brand standard.

M

Miscellaneous Tools & Procedures



PCIPAD

- HARD SURFACE GUEST ROOM FLOOR:** Using a **PerfectCLEAN 18" BLUE FRINGE MOP** and the **SDX 50** or **60** start at the furthest point in the room from the door and mop to the door using a *figure-8* motion.
- SHOWER - GLASS SWING DOORS:** After cleaning inside glass panels use PerfectCLEAN Color-Coded **ORANGE SQUEEGEE** to clear all water from glass to eliminate water spots.
- SHOWER - SLIDING GLASS DOORS:** Insert the PerfectCLEAN **PADDLE** into a **ORANGE MITT**. Mist with disinfectant if required. Insert **PADDLE** into space between chrome support beam and glass sliding door and run along full length of the beam. Repeat on other side of beam. Remove **ORANGE MITT** and now use to clean the toilet. Use additional disinfectant (as required). Start with the tank, then toilet seat and cover. **ROTATE MITT**- backside to front - and thoroughly wipe down bowl and base. When finished, the mitt goes directly into the soiled-laundry bag (1 mitt per toilet). You have now isolated the toilet from everything else in the Guest Room.
- 12" FLAT MOP FRAME with PUSH-IT's:** Secure **12" ORANGE FLAT MOP** followed by securing a **12" SCRUB & CLEAN ORANGE WIPER** to the frame using the PUSH-IT's. Scrub the shower walls using additional sanitizer/disinfectant as required. Remove wiper and use to scrub & clean tub, faucets, towel rack and any other surface
- PCIPAD:** If stained or wet, fold corners to middle with sheets, bundle up, bag and remove.
- HARDWARE WARRANTY:** Should hardware fail to function as per manufacturer's instructions, using a smart phone or camera, take a picture and email to info@perfectclean.com for replacement.



DO MORE · DO BETTER · DO IT FOR LE\$