



INSTALLATION INSTRUCTION

FOR CONNECTING WHIRLPOOL TRANSTEC II[®] ICEMAKER TO REMCOR TJ40.TJ80 –A, AB, ABC DISPENSER

(refer to installation drawing attached)

1. Install gasket in feed tube hole in hopper shown.
2. Push the ice feed tube up through the cabinet opening into the hopper, and lower it onto the icemaker nozzle.
3. Shift the icemaker position slightly as necessary for proper feed tube alignment. Permanently fasten the icemaker according to manufacturers instructions.
4. Check feed tube extension inside hopper, and remove and cut of necexxary to botain 1" extension.
5. Measure insulation length required between top of icemaker cabinet and bottom of foam insulation inside dispenser. Cut insulation 1" longer than measured length.
6. Slide insulation towerds top of edd tube, and install feed tube on icemaker nozzle using clamp provided.
7. Follow installation instructions provided with icemaker and dispenser.

FIGURE 1. INSTALLATION



DETAIL "B"




FIGURE 2. DEFLECTOR ASSEMBLY




FIGURE 3. HOPPER INTERIOR