

KIT #1993

INSTALLATION INSTRUCTIONS

For installing Ice-O-Matic Series C80/120 cuber on REMCOR® Model TJ400 dispenser.

1. Seal ice maker to top of dispenser as follows:
 - A. Locate gasket on dispenser top cover as shown.
 - B. Set ice maker onto cover and position according to Ice-O-Matic instructions.
2. Fasten brackets as shown. Drill holes and install sheet metal screws provided into ice maker and dispenser cover.
3. Follow the manufacturer's instructions to complete the installation of the ice maker.

I M P O R T A N T

Ice-O-Matic's bin level kit for REMCOR® Model TJ400 dispenser is required for this installation.

