

KIT # 2025

INSTALLATION INSTRUCTION

For installing ROSS-TEMP Models RCV-404/604-UF cubers on Remcor Model TJ250 dispenser.

- 1.) Seal icemaker to top of dispenser as follows:
 - a. Run a bead of RTV on the dispenser cover around the inside of the icemaker outline.
 - b. Set icemaker onto cover and position as shown.
 - c. Wipe away excess RTV.
- 2.) Fasten brackets as shown. Drill holes and install sheet metal screws provided into icemaker and dispenser cover.
- 3.) Follow the manufacturers instructions to complete the installation of the icemaker.

ROSS-TEMP ICEMAKER
MODEL RCV-404/604

SEAL ICEMAKER
TO DISPENSER WITH
RTV

ICEMAKER FLUSH
WITH DISPENSER.

SECURE MOUNTING
BRACKETS AS SHOWN
BY DRILLING .136 DIA.
HOLES IN ICEMAKER
CABINET AND DISPENSER
COVER FOR #10 SHEET
METAL SCREWS.

REMLOR MODEL
TJ250 DISPENSER
(REAR VIEW)

1/2"

