


KIT #2071

INSTALLATION INSTRUCTIONS

Hoshizaki Model KM452/631 Icemaker/Remcor Model TJ150 Dispenser

1. Seal icemaker to dispenser top cover as follows:
  - a. Locate outline of icemaker on dispenser cover as shown in attached sketch.
  - b. Run a bead of RTV around the inside of the icemaker outline on the cover.
  - c. Position the icemaker on the dispenser cover.
  - d. Wipe away any excess RTV immediately.
2. Using the mounting brackets as templates, locate and drill holes in the icemaker cabinet for the #10 sheet-metal screws provided in the kit. Install brackets.
3. Follow the icemaker manufacturer's instructions to complete the installation. Check that the ice level control bracket does not interfere with the agitator in the dispenser ice storage hopper. "Raise" the icemaker control bracket if required.

TJ150-K/HOSHIZAKI-KM452/631  
INSTALLATION



POSITION ICEMAKER ON  
DISPENSER TO COVER  
OPENING INTO STORAGE  
HOPPER.

APPLY RTV AROUND INSIDE  
OF ICEMAKER OUTLINE ON  
DISPENSER COVER TO FORM  
A SEAL.

USING BRACKET AS A  
TEMPLATE, DRILL .136  
DIA. HOLES INTO ICEMAKER  
CABINET FOR SHEET METAL  
SCREWS PROVIDED.