

KIT 2097

INSTALLATION INSTRUCTIONS

Important: Ice-O-Matic's bin level kit for Remcor Model TJ200/250 dispenser is required for this

For installing Ice-O-Matic Series C-20, C-40 and C-61 cubers on Remcor Model TJ200/250 dispensers.

1. Seal icemaker to top of dispenser as follows:
  - a) Run a bead of RTV on the dispenser cover around the outline of the icemaker frame (icemaker front panel removed) as shown in Figure 1.
  - b) Set icemaker onto cover.
  - c) Wipe excess RTV away immediately.
2. Follow Ice-O-Matic's instructions in their bin level kit for installing the bin level thermostat and routing the capillary tube into the storage hopper. Locate the mounting holes for the clamps that secure the brass bulb-well to the hopper wall as shown in Figure 2.
3. Secure icemaker to dispenser with mounting brackets provided as shown in Figure 1.
4. Follow Ice-O-Matic's instructions to complete the installation of the icemaker.

REV A  
9/1/68  
1 of 3

FIG. 1


INSTALLATION DETAILS  
ICE-O-MATIC C-20, C-40 & C-60 ICEMAKERS

1- FRONT LID OF DISPENSER SHOWN  
REMOVED FOR INSTALLATION.

2- FRONT PANEL OF ICEMAKER REMOVED  
FOR THIS INSTALLATION.

CENTER ICEMAKER OVER  
OPENING ON DISPENSER COVER.

MOUNT BRACKETS  
TO ICEMAKER AS  
SHOWN.



IMPORTANT:  
FOLLOW ICE-O-MATIC BIN LEVEL  
KIT INSTRUCTIONS FOR INSTALLING  
BIN LEVEL THERMOSTAT. SEE FIG. 2  
FOR LOCATING BRASS BULB WELL IN  
HOPPER.

5302  
2 of 3  
8711b

FIG. 2  
 LOCATING ICEMAKER BIN LEVEL T'STAT  
 CAPILLARY TUBE (FRONT DISPENSER LID REMOVED)

