

## **INSTALLATION INSTRUCTION**

---

FOR

### **SCOTSMAN CM51002 SERIES ICE MAKER (WITH SONAR CONTROL)**

### **ON REMCOR® MODEL TJ300 SERIES ICE DISPENSER**

**NOTE:** If dispenser has a flat stainless steel cover installed, it should be removed and discarded. Use following instructions to assemble new cover and ice maker. Use page 2 for reference.

1. Seal cover to dispenser as follows:
  - A. Unpack new cover assembly and run a bead of RTV on the cover bottom flanges to mate with dispenser hopper.
  - B. Set cover onto dispenser, be careful not to disrupt dispenser cabinet labels.
  - C. Wipe excess RTV away immediately.
  - D. Cover must be sealed completely to dispenser hopper.
2. Seal icemaker to dispenser cover.
  - A. Run a bead of RTV on the dispenser cover around the outline of the icemaker frame sides and rear.
  - B. Set icemaker onto cover.
  - C. Wipe excess RTV away immediately.
3. Secure icemaker to dispenser with mounting brackets provided as shown on page 2. Drill holes and install sheet metal screws provided into icemaker cabinet. Drilling must not interfere with ice maker components.
4. Follow the manufacturer's instructions to complete the installation of the icemaker.

**REMOVE SCREWS AND TURN  
BRACKET AROUND 180°.  
REPLACE SCREWS USING  
BRACKET AS A TEMPLATE  
DRILL (4) .1360 HOLES FOR A  
#10 SHEET METAL SCREW IN  
ICEMAKER CABINET.  
DRILLING MUST NOT  
INTERFERE WITH ICE MAKER  
COMPONENTS.**

**REMCOR TJ300 / SCOTSMAN CMS1002**

**LOCATE ICEMAKER FLUSH  
WITH REAR OF DISPENSER.**

**APPLY RTV ALONG BOTTOM  
EDGE OF ICE RAMP AND  
HOPPER FLANGE. COMPLETE  
COVER MUST BE SEALED TO  
HOPPER.**

**APPLY RTV AROUND ICEMAKER  
OUTLINE ON DISPENSER COVER  
TO SEAL ICEMAKER.**

**REMOVABLE FRONT LID  
FOR MANUAL ICE FILLING.**

***FRONT OF DISPENSER***