

To: James Prescott

Company Name

City, State, Zip Code

From: Arlene kent **MEMORANDUM**

100 Business Street

617.555.1212

Subject: 92094



November 6, 1997



rd to James Prescott, 2 camera ready copies.



INSTALLATION INSTRUCTIONS

FOR

KIT 02386 INSTALLING IAC/IWC 330, 530, 630, 830, 1030 AND 1230 SERIES ICEMAKERS ON REMCOR MODEL TJ300 SERIES DISPENSERS

1. Seal icemaker to dispenser top cover as follows:
 - A. Locate outline of icemaker on dispenser cover as shown in attached sketch.
 - B. Run a bead or RTV around the inside of the icemaker outline on the cover.
 - C. Position the icemaker on the dispenser cover.
 - D. Wipe away any excess RTV immediately.
2. Secure icemaker to dispenser. Using the mounting brackets as templates, locate the drill holes in the icemaker cabinet for the #10 sheet-metal screws provided in the kit. Drilling must not interfere with icemaker components.
3. Install insulation strip on removable lids as shown.
4. Using the lid as a template, locate and drill holes in the dispenser top cover for #10 sheet metal screws.
5. Follow the icemaker manufacturer's instructions to complete the installation of the icemaker.




FIGURE 1. INSTALLATION INSTRUCTIONS