

# BRIG POWER UNIT

## INSTALLATION GUIDE


SUGGESTED MINIMUM CREW: 1  
APPROXIMATE INSTALL TIME: 30 Min

### TOOLS REQUIRED:

Tape Measure  
Phillips Screwdriver / Bit  
Drill / Screwdriver


### HARDWARE:

Qty - 1 Power Unit (Either USB A+B or standard Outlet Style)  
Qty - 1 Power Unit Housing [pn 235155-50-858-01]  
Qty - 1 Power Unit Housing Spacer Sleeve [pn 235155-50-858-01]  
Qty - 4 #6 x 5/8" Pan Head, Phillips Drive Wood Screw [pn 712368-50-855-01]  
Qty - 4 #6 Flat Washer  
Qty - 1 pack of 5 Self Adhesive, Wire Clips [pn 460373-50-854-01]




### ASSEMBLY OF POWER UNIT

Align spacer sleeve tabs with unit housing notches and press together.  
Snap power unit face onto main unit.  
Feed power cable and unit body through housing.



### POWER UNIT LOCATION

Power units can be located anywhere between legs as shown above. The most common placement is as shown.



### MOUNTING POWER UNIT

Once position is chosen, align face of power unit with face of wood deck above and secure in place with 4 wood screws and washers.  
Power cable to feed into deck and travel to source. Use wire clips for any additional wire management.