


Site Preparation for Above Ground Transportable Tanks

IMPORTANT – Warranty will be voided if the site is not prepared to these requirements.

1) Choose the site

Things to remember:

- Can the delivery truck get in?
- Are there any overhead wires, septic systems, drains etc in the road?




2) Level the site

Things to do:

- a) Measure out the size of the tank.
- b) Allow a little extra for the bedding material.
- c) Use a spirit level and a length of straight timber to check the level.

Make sure:

- You put the tank on stable ground.
- You **DO NOT** put the tank on fill or directly on a concrete slab.




3) Smooth the site

Things to do:

- a) Spread a 50mm layer of crusher dust or sand as bedding over the site.
- b) Check the site again with the spirit level and timber to make sure it is still level.

Make sure:

- You take out any irregularities in the natural ground.




Delivery

The delivery truck must get to the edge of your site, with its rear wheel on level ground. The tank is positioned directly from the truck.

Finishing

Rake some topsoil around the base of the tank to protect the bedding material from erosion.



Filling

Important: DO NOT shock-fill the tank (fill quickly).
 Make sure it is gradually filled (according to 'Everlast Filling Instructions').

When you first fill the tank, you may notice some wet areas. This is normal, make sure you leave water in the tank & they will take up.

In-Ground Tanks See 'Site Preparation for Underground Tanks'.

| Tank Capacity Ltrs (Gal) | Tank | | Access Height (mm) |
|-----------------------------|-------------|------------------|-----------------------|
| | Height (mm) | Width (mm) | |
| 10,000 (2,200) | 2400 | 2450 | 3800 |
| 15,000 (3,300) | 2440 | 3000 | 3800 |
| 20,000 (4,400) | 2440 | 3450 | 3800 |
| 23,000 (5,000) | 2800 | 3450 | 4150 |
| 25,000 (5,500) | 3000 | 3450 | 4350 |
| 35,000 (7,500) | 2800 | 3450 x 4875 oval | 4150 |