


A photograph of a room interior. A light-colored roller shade is partially rolled up over a window. To the left of the window, a framed abstract artwork hangs on the wall. In the foreground, a dark wooden chair with a curved back is visible. To the right of the chair, a woven basket holds a white, fringed blanket. The floor is made of light-colored wood, and a patterned rug is partially visible in the bottom right corner.

EVERHEM

*Roller Shade
Installation Guide
Outside Mount – Cordless*


The Tools You'll Need




TAPE MEASURE




STEP LADDER




PENCIL




LEVEL




POWER
DRILL




SAFETY
GOGGLES




$\frac{7}{64}$ " DRILL
BIT



$\frac{1}{4}$ HEX
SOCKET
BIT




PHILLIPS
HEAD
SCREWDRIVER



$\frac{1}{4}$ HEX
EXTENDER
TIP

The Hardware We Provide



WALL
MOUNTING
BRACKETS



WALL
MOUNTING
SCREWS



HEADRAIL
MOUNTING
SCREWS




WALL
ANCHORS


Step 1

Determine shade's mounting height. The length of your shade is written on its packaging and is based on your custom measurements. To determine your shade's mounting height, deduct 1" from your shade's length to account for the height of the headrail. If you ordered a 36" W x 48" L shade, your shade's length is 48". Your shade's mounting height is 47".

SIDE VIEW




FRONT VIEW



*The valance illustration uses transparency to provide a clearer view of the shade's inner structure.


Step 2

Mark the mounting height. Standing at the center of your window, measure upward from the lowest point the shade will cover when closed to the mounting height determined in STEP 1. Align your tape measure with the window center point, then mark the mounting height of your shade.




Step 3

Mark the bracket mounting positions. Ensuring your shade is centered horizontally over your window, mark where you will mount your brackets along the mounting height marked in STEP 2 . Brackets should be evenly spaced along the headrail to support the shade.




Step 4

Mark bracket screw holes. Place a wall mounting bracket against the wall and align it so the top is flush with the bracket mounting position mark made in STEP 3. Mark the position of the screw hole on the wall. Repeat this process at each remaining bracket mounting position mark, making sure all screw hole marks are level with one another.





Step 5

Drill the marked bracket screw holes.
Using your power drill and the 7/64"
drill bit, drill into the first bracket
screw hole marked in STEP 4.




Step 5A

If your drill doesn't hit a wooden stud, install one of the provided wall anchors into the predrilled hole using a Phillips head screwdriver. If your drill does hit a wooden stud, no anchor is required. Repeat this process for each bracket screw hole marked in STEP 4.



Step 6



Secure brackets to the wall. Using your power drill and $\frac{1}{4}$ hex socket screw bit, secure each wall mounting bracket to the wall using one of the provided wall mounting screws.



Step 7

Place shade on the brackets. *Shades wider than 72" may require assistance.


With the Valance facing right side up, carefully lift the Valance and firmly set it into place, so that the shade rests on top of the wall mounted brackets. Slowly let go so that the shade remains in place and does not slide off the brackets.



Step 7


Place shade on the brackets. *Shades wider than 72" may require assistance.

With the Valance facing right side up, carefully lift the Valance and firmly set it into place, so that the shade rests on top of the wall mounted brackets. Slowly let go so that the shade remains in place and does not slide off the brackets.




Step 8

Secure Shade to brackets. Making sure your shade is centered, use your power drill, your $\frac{1}{4}$ hex socket screw bit and the provided headrail mounting screws to secure the brackets directly to the valance's headrail.



IMPORTANT: Due to the tubing present under the headrail, it is likely that you will need to drill at an angle in order to reach the bracket.



You're Done!

Now your shade is ready for safe usage. Pull the shade down, then guide the shade up slowly as it draws open; pull the shade down to close the shade or to hold the shade's desired position.

PLEASE NOTE: The cordless mechanism is delicate as it functions via a tension spring. The application of unnecessary force can compromise the mechanism. Handle with care.

EVERHEM