

## User Manual


# Safety Instructions

Read all instructions before you use this device. Do not make any changes or create settings that are not described in this manual. If physical damage, loss of data or damage is caused by failure to follow instructions, the warranty does not apply.

- 1. To reduce the risk of fire or electric shock, do not expose the device to rain or moisture. Objects filled with liquids, such as vases, should not be placed on this
- 2. Do not place this device on soft surfaces such as tablecloths or carpets, otherwise the device could be a fire hazard.
- 3. Do not place this device in areas susceptible to excessive dust and dirt or near any appliance generating a strong magnetic field.
- 4. To prevent overheating, do not block or clog the
- 5. Never place this device in a confined space. Always leave enough space around this device for ventilation.
- 6. Protect this device from overexposure to direct sunlight. heat, large temperature fluctuations and moisture. Avoid extreme temperatures.
- 7. When this device is running for a long period of time, the surface may become hot. Shut it down immediately and unplug the charger. Resume operation after this device has cooled down
- 8. Always handle this device with care. Avoid touching the lens. Do not allow children to handle the device without supervision.
- 9. Use attachments or accessories specified by the manufacturer only.
- 10. Avoid extreme vibration as it may damage the internal components



Projector × 1














Projector User Manual × 1

Power Cable × 1

Package List

Clean Tool × 1

Overview



### 1. Blurry Image


Go to Settings - Projection Settings - Auto Four Keystone Correction - Turn on the Auto Four Keystone Correction or enter Manual Keystone to adjust the

Press the focus button on remote control to get the

### 2. Mounting Hole


Adopting a single mounting hole dual-use design, the projector is compatible with the standard camera tripod and 1/4 inch screw projector tripod stand.

# Remote Control




- 1. Do not submerge the remote control in the water.
- 2. Do not put the remote control near fire or in wet or hot
- 3. Do not use old and new batteries together in the
- 4. Please take the batteries out if not using the remote control for a long time to avoid battery leakage.
- 5. Please point the remote control toward the IR receiver.
- 6. Please use the remote control within 6 meters distance and 30 degree angle.

# **Getting Started**



Plug the power cable to the projector. Press power button to turn on the projector.



Use the manual focus by pressing the "Focus" button on the remote control.

Make sure the projector is horizontal to the projector screen.

# Cleaning Method




1. Get cleaning tools ready.


2. Use tweezers to pry off

the bottom cover.







3. Clean the projector by the cotton swab.





4. Reinstall the bottom cover after cleaning.

## Homepage status bar icon











### File Management

Insert the U disk, click the FileManager icon on the homepage. The content of U disk could be read, such as video, audio, picture, etc.



### **Network Setting** Settings - Network Settings- WiFi Switch > Turn on WiFi

Switch. Choose the network and type the password that you want to connect to.



## Bluetooth Setting

Settings - Bluetooth- Bluetooth Settings > Turn on Bluetooth Switch. Click Search for Bluetooth devices and pair the device that you want to connect to.



## **Projection Settings**

Settings - Projection Settings > Set the display settings, installation mode, device mode, digital zoom, screen zoom, auto keystone correction, manual keystone and reset keystone correction.





## Language and Keyboard


Language settings

Settings - Language and Keyboard > Support to change language and input keyboard.



### Other Settings

Settings - Other Settings > Set the external input at boot button sound, screen saver, scheduled power off, restore factory settings, account settings.



# **Date and Time Settings**

Settings - Date and time settings > Set the date, time, time zone, hour format.



## **Application Settings**

Settings - Application Settings > Check the app information and clear the app data.



# **Android Wireless Mirroring**

Enter transcreen app on the mobile phone, make sure the mobile phone and the projector connect the same

Search the projector device name on your phone, click connect to share screen.



Follow the tips on the screen. go to https://transcreen.app and download transcreen app.

Sections to Asset

Tandorsen for dis

Testimento No.



tranScreen



## Miracast Mirroring

Click "START" on the screen. Then will go to Miracast mirroring interface. Make sure the mobile phone and projector connect the

same network Follow the tips on the screen, according to your phone

mirroring function to search the device for sharing





# Android Wired Mirroring

Connect the Android mobile phone to the USB port of projector by USB cable. At the first connection, the mobile phone will come out

the tips for downloading the mirroring app. After installation, accept the mirroring at the pop-up window and then share screen.



Scan the QR code or download the APP from the URL.

https://transcreen.app/linedisplay



## AirPlay Mirroring

Make sure the mobile phone and projector connect to the same network. Click "Screen Mirroring" on your phone. Find the projector

device name and share screen.



### Apple Wired Mirroring

Connect the iOS mobile phone to USB port of projector by USB cable.

After connection, input the passwords then share screen.



### FCC STATEMENT: This device complies with Part 15 of the FCC Rules. Operation is subject to the following two

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired Warning: Changes or modifications not expressly approved by the party responsible for compliance

could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device. pursuant to Part 15 of the ECC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no quarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Regrient or relocate the receiving antenna. Increase the senaration between the equipment and receiver

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

### FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator &

### ISED Statement

English: This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

(1) This device may not cause interference

(2) This device must accept any interference, including interference that may cause undesired

operation of the device The digital apparatus complies with Canadian CAN ICES-3 (B)/NMB-3(B).

French: Cet appareil contient des émetteurs/récepteurs exempts de licence qui sont conformes aux RSS exemptés de licence d'Innovation, Sciences et Développement économique Canada, L'exploitation est soumise aux deux conditions suivantes :

(1) Cet appareil ne doit pas provoquer d'interférences.

(2) Cet appareil doit accepter toute interférence, y compris les interferences susceptibles de provoquer un fonctionnement indésirable de l'appareil.

l'appareil numérique du ciem conforme canadien peut - 3 (b) / nmb - 3 (b).

This device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS 102 RF exposure, users can obtain Canadian Information on RF exposure and

cet appareil est conforme à l'exemption des limites d'évaluation courante dans la section 2.5 du cnr -102 et conformité avec rss 102 de l'exposition aux rf. les utilisateurs peuvent obtenir des données canadiennes sur l'exposition aux champs rf et la conformité.

This equipment complies with Canada radiation exposure limits set forth for an uncontrolled

Cet équipement est conforme aux limites d'exposition aux rayonnements du Canada établies pour un environnement non contrôlé

This equipment should be installed and operated with minimum distance 20cm between the radiator & Cet équipement doit être installé et utilisé à une distance minimale de 20 cm entre le radiateur et votre

HDMI"

HIGH-DEFINITION MULTIMEDIA INTERFACE

Trade dress and the

Licensing Administrator, Inc.

The terms HDMI, HDMI High-Definition Multimedia Interface, HDMI

HDMI Logos are trademarks or registered trademarks of HDMI

