




USE AND CARE GUIDE

FOR



1 Safety Information


Read the precautions and instructions in this manual before installing and using this lock. Save this manual for future reference.

WARNING:
If the door needs to be drilled, be familiar with how to use your drill safely, and understand all the door preparation steps before proceeding.

CAUTION:
Before beginning the installation, please read and understand the entire manual.


NOTE:
To ensure a long lasting finish, remove the locks, or do not install the locks, prior to painting your door. Periodically clean the locks with mild soap and a soft cloth. Do not use abrasives or harsh chemicals, and avoid sharp or scratching objects.

2 Pre-Installation – Tools Required/Hardware Included




Part	Description	Quantity
AA	Mounting Screws	2
BB	Deadbolt mounting screws	2
CC	Latch/Strike Plate Screws	4
DD	Deadbolt Strike Plate Screws	2

Note: Not to scale.




Part	Description	Quantity
A	Key	2
B	Exterior assembly	1
C	Interior reinforcing plate	1
D	Interior assembly	1
E	Deadbolt Latch	1
F	Faceplate	1
G	Strike Plate	1
H	Reinforcement Plate	1
I	Dust Box (Optional)	1
J	Mounting Ring with Anti-pry Shield	1
K	Adapting ring	1 OR 2
L	Interior Rose Plate	1
	6-pin interchangeable core spacer (For SFIC lock only)	1

- ① Double cylinder
- ② Single cylinder
- ③ Deadlock with blank plate
- ④ Blank plate outside thumbturn inside



IC CORE :

- ① Double cylinder
- ② Single cylinder




NOTE:
Single IC Core deadbolt
For 1-3/4"~2"(45~51mm) door thickness, the Adapting Ring **K** is not needed.
For 1-9/16"~1-3/4"(40~45mm) door thickness,the Adapting Ring **K** is required.

3 Pre-Installation (continued) – Door Preparation

NOTE:
If your door already has holes, skip to Installation.


1 Using the template, mark the door and drill the holes, and chisel out a mortise.



NOTE:
Drill from both sides to avoid wood splitting.


2 Prepare the door jamb – using the strike plate as a pattern, drill the latch and screw holes, and chisel out a mortise until the strike plate fits flush.

NOTE:
To assure proper lockset function, the holes in the door jamb must be drilled 1-1/8" (28 mm) deep.



TEMPLATE



NOTE:
Double check your product for the correct hole sizes.



4 Installation

1 INSTALLING THE LATCH

A. Attach the correct faceplate





B. Set the latch backset





Fixed Latch With 2-3/8" (60mm) Or 2-3/4" (70mm) Backset can not be adjusted

C. Install the latch


CAUTION:
Be sure the latch cam is upright before making any backset adjustment.



2 INSTALL CYLINDER DEADBOLT



3 INSTALLING THE STRIKE PLATE



4 Install Interchangeable Core

