


Procedure Card for X1-4000

ECSTASY/BATH SALTS IDENTIFICATION

Substance Test



As a precaution, gloves and eye protection should be worn when handling drug substances and using test units. Do not puncture any part of unit. Do not remove probe once a capsule is broken. In the unlikely event of a spill, rinse affected area thoroughly with water. Keep out of reach of children. All results are presumptive. If necessary, further testing by a competent drug testing lab can provide additional identification.



Secure probe est Preparation into test unit. Press firmly.

Do not continue probe is secured properly in place. the kit, squeeze on the circle of Chamber 1 until the capsule breaks.

test unit for 2-3 seconds.

Results



The appearance of a violet color strongly indicates the presence of **Ecstasy/MDMA** or its analogues.

The color may take up to 3 minutes to develop.

The appearance of a yellow color indicates the presence of Bath Salts such as MDPV, Methylone, or Butylone.



If none of the above colors develop, the above listed drugs are not present.



Proceed to Dilution (steps 6-9), regardless of whether or not a color appeared.



Dilution

From both sides of the kit, squeeze 6 on the circle of Chamber 2 until the capsule breaks



Gently shake test unit for 2-3 seconds.



Wait 5 minutes The test window will warm up. This is normal.

From both sides of the kit, squeeze 8 on the circle of Chamber 3 until the capsule breaks.



Gently shake test unit for 2-3 seconds.



The test window will warm up. This is normal

m

Disposal

After Dilution, the test kit is safe to dispose of in the trash.



Manufactured by IDenta Ltd

www.identa-corp.com Patented Technology • Made in Israel