



W
▲

VICTORIA

110




1.



2. Insert the hole of the rod (B) into the lower ring (A).




3. Place a NUT (C).




4. Insert the hole of the rod (B) into the upper ring (A).



5. Place a NUT (C).



6. Repeat steps 2 through 5.



7. Place the top of piece D on the top ring.




8. You can fold the piece in this way.




9. Place the bottom of piece D on the bottom ring.




10.




11. Place the top of piece D on the top ring.



12. Place the bottom of piece D on the bottom ring.



13.




14. Repeat steps 6 through 11.




15.


PARTS



x 1



x 1




x 8



x 4

Nuts
x 8



x 1
x 1
x 2
x 1

x 8

MEASURES

D 110 cm / 43.3 in

H 60 cm / 23.6 in

BULB 100 w max.



This product requires professional installation.
Please contact a certificate electrician.