



# INSTALLATION INSTRUCTIONS

## Water Based Urethanes

---

### TOOLS / EQUIPMENT NEEDED

---

- Brushes for cutting in edges
- 5 mil or 10 mil 18" roller sleeves plus cage with pole attachment (9" can be used, it just takes longer)
- Drill with mixing paddle
- Mixing pails and measuring pails
- Small pail for use with brush to do edges
- Shop Vac
- Broom
- Gloves for mixing and coating
- Garbage bags
- Small tarp for mixing station
- Paint stir sticks

---

### INSTALLATION STEPS

---

1. Prepare surface for proper bonding by ensuring the surface is clean. If you are applying the urethane over an existing coating then it is advisable to use sanding screens so that scratch marks don't show up in the urethane coatings. The sanding screens will cause an obvious gloss loss on all areas.
2. Vacuum floor to ensure all dust is removed (this is critical for adhesion of the coating to the concrete)
3. Prepare all tools necessary for coating (drill, pails, brush, rollers, tray, gloves, etc.)
4. Mix desired amounts of parts A and B in a clean mixing pail. Apply at a rate of 300-400 square feet per gallon. Immediately begin brushing edges and rolling out material to evenly coat floor. Avoid any puddles. Always keep a wet edge.

---

**\*Remember to check mix ratios prior to mixing product.**  
**\*\*Waterborne urethanes may be thinned up to 10% with water.**

---