

## LET'S GET STARTED

**CHARGE UP:** Your POWER 300 comes partially charged due to transportation requirements. While ready to go, we recommend you FULLY CHARGE before use. The POWER 300 can be used while charging. The cooling fan will automatically engage when needed.

**TIP: Wall outlets provide the fastest recharge time (usually 2-3 hours)**

**PRESS & GO:** To start the power flow, PRESS any button to activate the display, then press the button above the required port. You'll hear a beep when a port is active. All ports can be used simultaneously. Power ports will automatically turn off after 2 hours for AC ports and 8 hours for DC ports if no load/device is connected.

**TIP: To extend battery life, we suggest you manually switch off when power is no longer needed**

**USB-C:** Duracell's AUTO DETECT feature will automatically start the flow of power when a device is connected to the USB-C IN/OUT port.

**TIP: AUTO DETECT recognition time can vary depending upon the device/cable**

**AC POWER PORTS:** The POWER 300 is ideal for low-power devices, such as phones, tablets, laptops, TVs, fans, drones, cameras, and flood lights. It is not designed for high-load devices, such as refrigerators, toasters, coffee makers, microwaves, or blenders. While all AC plugs will fit into the unit, power flow may not be sufficient to power high drain devices properly.

**TIP: Check your device's rating label to ensure it does not draw more than 300W**

**READY FOR NEXT TIME:** We recommend you STORE at 80% CHARGE. While self-discharge is a normal property for Lithium-ion batteries, your POWER 300 will be ready for use for over 1 year.

**TIP: We recommend you recharge every 3-6 months to prolong the battery cycle life**



## IMPORTANT SAFETY INFORMATION

1. Read all the instructions before using the Duracell Power 300 (hereinafter referred to as Unit).
2. To reduce the risk of injury, close supervision is necessary when the Unit is used near children.
3. Do not expose the Unit to rain or snow.
4. Use only recommended Duracell accessories and chargers.
5. Do not expose the Unit to fire or excessive temperature. Any such exposure to fire or temperature above 140° F (60° C) may cause an explosion. Do not use near flammable gases or fumes.
6. Do not use the Unit with damaged wires or plugs. It may cause an electric shock.
7. Do not use the Unit if it is damaged or modified. Damage or modification of the Unit, including the lithium-ion battery pack within the Unit, may exhibit unpredictable behavior resulting in fire, explosion or risk of injury.
8. Please make sure to use the Unit in a ventilated environment. Do not restrict the ventilation of the Unit in any way during usage.
9. During storage, keep the Unit in a dry and ventilated place to avoid moisture and electric shock.
10. Do not disassemble, repair, or modify the Unit or the battery pack. It may cause fire, explosion, injury, and unpredictable risks.
11. This Unit has no serviceable parts.

Please visit [www.duracell.com](http://www.duracell.com) or call Duracell Consumer Relations at 800-551-2355 if you experience any problems with the Unit.

This device complies with Part 15 of the FCC Rules and Class B Digital Device limits which provide protection against interference in a residential installation. Operation is subject to the following two conditions: (1) this device may not cause harmful interference (2) this device must accept any interference received, including interference that may cause undesired operation. This device generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause interference to radio/tv communications for which the manufacturer is not responsible. Should interference occur, correct by connecting the device to another outlet on a different circuit.