



ORIGIN DUCTWORKS

IN-CUT

In-Cuts, also known as Saddle Taps, are branch fittings used to create a new duct line by tapping into an existing trunk. This is done by cutting a hole in the main duct and saddling the In-Cut over the opening. They are fastened with tech screws and sealed with caulk to ensure a secure and airtight fit.

Øin.	Weight Lbs.
3	1.3
4	1.5
5	2.2
6	2.8
7	3.5
8	4.5
9	5.4
10	6.5
11	7.6
12	8.8
13	11.2
14	13.9
15	15.8
16	17.2
17	19.3
18	21.3
19	23.3
20	25.6
21	27.8
22	30.5
23	33
24	35.4
25	37.8
26	40.3
27	42.5
28	45
29	50.5
30	56.5
31	59.8
32	63
33	63.8
34	67.4
35	69.5
36	71.4
37	73.8
38	76.8
39	79
40	81.4



SNAPLOCK MATERIAL OPTIONS

GALVANIZED				STAINLESS STEEL			
Gauges	Size in		Gauges	Size in			
	Min Øin.	Max Øin.		Min Øin.	Max Øin.		
STD.	22	3	12	22	3	12	
	20	13	24	20	13	24	
OPT.	18	4	24	18	8	24	
	16	8	24	16	8	24	
	14	8	24				

FLANGED MATERIAL OPTIONS

GALVANIZED				STAINLESS STEEL			
Gauges	Size in		Gauges	Size in			
	Min Øin.	Max Øin.		Min Øin.	Max Øin.		
STD.	22	3	12	22	3	12	
	20	13	24	20	13	24	
	18	26	30	18	26	30	
	16	32	40	16	32	40	
	14	42	50				
OPT.	12	52	72	20	4	12	
	20	4	12	18	4	24	
	18	4	24	16	8	30	
	16	8	30				
	14	8	50				
	12	10	72				
	10	12	72				